

O : Parts Location

	Code	See Page	Code	See Page	Code	See Page
ſ	C6	44	J1	45	P7	45

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1H	- 29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
1K			

∇

: Ground Points

Code	See Page	Ground Points Location
IA	54	Left Kick Panel