Sound Quality is Bad Only when CD is Played (Volume is Too Low)

1 OPERATION USING ANOTHER CD

- (a) Replace the CD with another one and recheck.
 - (1) Check the installation of the radio receiver assembly.

OK:

The malfunction disappears.

NG

REPLACE RADIO RECEIVER ASSEMBLY

OK

CD IS FAULTY



CD cannot be **Ejected**

AV

1 CHECK OPERATION

- (a) Press EJECT and check operation.
 - (1) Press the CD EJECT switch of the radio receiver assembly for 2 seconds or more to see if the CD is ejected.

OK:

The CD is ejected.

HINT:

If the CD is not ejected, bring the vehicle in for repair. Do not attempt to remove the CD by force.

NG

REPLACE RADIO RECEIVER ASSEMBLY

OK

2 OPERATION USING ANOTHER CD

- (a) Replace the CD with another and recheck.
 - (1) Replace the CD with another normal one to see whether the same trouble occurs again.

OK:

The malfunction disappears.

NG]

REPLACE RADIO RECEIVER ASSEMBLY

OK

CD IS FAULTY