

RADIO ANTENNA POLE

COMPONENTS









- 1. REMOVE PULL TOP ANTENNA POLE SUB ASSEMBLY
 - (a) Remove the pull top antenna pole sub-assembly by turning it counterclockwise.



INSTALLATION

- 1. INSTALL PULL TOP ANTENNA POLE SUB ASSEMBLY
 - (a) Install the pull top antenna pole sub-assembly by turning it clockwise.

