

FUEL TANK CAP

INSPECTION

- 1. INSPECT FUEL TANK CAP ASSEMBLY
 - (a) Check the appearance.
 - (1) Visually check the fuel tank cap and gasket for any deformation and damage. If necessary, repair or replace the cap and/or gasket.

