

ROOF DRIP SIDE FINISH MOULDING

REMOVAL

1. REMOVE ROOF DRIP SIDE FINISH MOULDING

- (a) Apply protective tape to the outer circumference of the roof drip side finish moulding, as shown in the illustration.
- (b) Using a heat light, heat the roof drip side finish moulding.

Heating temperature:

40 to 60°C (104 to 140°F)

NOTICE:

Do not heat the roof drip side finish moulding and vehicle body excessively.

- (c) Using a moulding remover, disengage the 2 clips and remove the roof drip side finish moulding.NOTICE:
 - Do not remove the clips from the vehicle body.
 - If the clips are damaged or removed accidentally, replace them.



1. INSTALL ROOF DRIP SIDE FINISH MOULDING HINT:

Use the following steps (a) to (c) only when replacing the clips.

- (a) Remove the tape that remains on the mounting surface of the vehicle body, and clean the surface with white gasoline.
- (b) Using a heat light, heat the clip installation surfaces of the vehicle body and roof drip side finish moulding.
- (c) Install new clips in the positions shown in the illustration. Press the clips by hand.

Specification


Area	Measurement
а	7.0 mm (0.276 in.)
b	8.2 mm (0.323 in.)


NOTICE:

After pressing the clips, wait 30 minutes or more before installing the roof drip side finish moulding.

HINT:

- Minimum hardening time: 30 minutes
- Time needed for complete hardening: 24 hours





(d) Engage the 2 clips and install the roof drip side finish moulding.

