

MCU - XIAO ESP32C3

Seed	Meaning	Diagram description
VBus	5V	Connect to batteries
3V3	3V3 (3.3 V)	P_IMU, 3.3 Volts, connect to IMU
D0	Analog	C3_anlg_A
D1	Analog	C3_anlg_B
D2	Analog	C3_anlg_C
D4	SDA	SDA, on IMU
D5	SCL	SCL, on IMU
D6	Digital	Int, connect to IMU
D7	Digital	P1, FSR set 1
D8	Digital	P2, FSR set 2
D9	Digital	P3, FSR set 3
GND	Ground	Ground

IMU - MPU 6050

MPU 6050	Meaning	Diagram Description
VCC	3V3 (3.3V)	P_IMU, Connect to MCU
SDA	SDA	SDA, connect to MCU
SCL	SCL	SCL, connect to MCU
INT	Int	Int, connect to MCU
GND	GND	GND/Total_GND