## **SOPine Pin Assignments**

Ver 0.1

204-Pin SOPine Front		204-Pin SOPine Back	
Pin	Pin Definition	Pin	Pin Definition
1	HBIAS	2	EAROUT_P
3	HPOUTR	4	EAROUT_N
5	HPOUTL	6	HS-MIC
7	GND	8	GND
9	MIC2P	10	HPOUTFB
11	MIC2N	12	KEYADC
13	PL11-IR_RX	14	BT-RST-N
15	PL8-S_TWI_SCK	16	AP-WAKE-BT
17	PL9-S_TWI_SDA	18	BT-WAKE-AP
19	GND	20	GND
21	WL-REG-ON	22	HP-DET
23	WL-WAKE-AP	24	PL7
25	PC5-eMMC_CLK	26	LCD-BL-EN
27	PB5-I2S_BCLK	28	PB4-I2S_SYNC
29	PB7-I2S_DIN	30	PB3-I3S_MCLK
31	GND	32	GND
33	PB9-UART0_RX	34	PB8-UART0_TX
35	PB0-UART2_TX	36	PB2
37	PH3-TW1_SDA	38	PH8-OWA_OUT
39	PB6-I2S_DOUT	40	PD7
41	GND	42	GND
43	TP-SCK	44	PD5-UART4_CTS
45	PD6	46	TP-SDA
47	RGMII-TXCTL	48	RGMII-RXD0
49	PD1-SPI1_CLK	50	LCD-RST#
51	RGMII-RXD1	52	PD4-UART4_RTS
53	MDC-PWM0	54	CSI-D1
55	GND	56	GND
57	PD2-SPI1_MOSI	58	CSI-PCLK
59	CSI-D5	60	PD0-SPI1_CS
61	PD3-SPI1_MISO	62	PH2-TW1_SCK
63	WL-SDIO-D0	64	TP-INT
65	CSI-D3	66	PH6
67	TP-RST	68	PH5

Sheet1

69	GND	70	GND
71	PH7	72	WL-SDIO-CLK
73	RGMII-RXD3	74	RGMII-CLKIN
75	PB1-UART2_RX	76	MDIO
77	PH9	78	RGMII-TXD1
79	RGMII-TXCK	80	RGMII-TXD3
81	GND	82	RGMII-TXD2
83	RGMII-RXD2	84	GND
85	RGMII-TXD0	86	BT-PCM-CLK
87	RGMII-NULL	88	BT-UART-CTS
89	RGMII-RXCTL	90	BT-UART-RX
91	RGMII-RXCK	92	CSI-RST-F
93	GND	94	GND
95	CSI-D0	96	CSI-D2
97	BT-PCM-DIN	98	CSI-SCK
99	BT-PCM-SYNC	100	CSI-HSYNC
101	CSI-VSYNC	102	CSI-MCLK
103	GND	104	GND
105	CSI-D4	106	WL-SDIO-D2
107	CSI-D6	108	WL-SDIO-CMD
109	CSI-STBY-F	110	WL-SDIO-D1
111	CSI-D7	112	WL-SDIO-D3
113	CSI-SDA	114	GND
115	GND	116	DSI-D1P
117	BT-UART-RTS	118	DSI-D1N
119	BT-UART-TX	120	DSI-D0P
121	BT-PCM-DOUT	122	DSI-D3P
123	DSI-D0N	124	DSI-D3N
125	GND	126	DSI-D2P
127	DSI-CKP	128	GND
129	DSI-CKN	130	PC8-eMMC_D0
131	DSI-D2N	132	PC7
133	PC15-eMMC_D7	134	PC0-SPIO_MOSI
135	PC4	136	HDMI-HTX0P
137	GND	138	HDMI-HTX0N
139	HDMI-HTX2N	140	GND
141	HDMI-HTX2P	142	HDMI-HTX1N
143	PC2-SPIO_CLK	144	PC16-eMMC_RST
145	HDMI-HTX1P	146	PC12-eMMC_D4
147	HDMI-TXCP	158	PC3-SPIO_CS
149	GND	150	-SPIO_MISO-eMMC_DS

		Sheet1	
151	HDMI-TXCN	152	GND
153	PC9-eMMC_D1	154	PC6-eMMC_CMD
155	PC14-eMMC_D6	156	PC10-eMMC_D2
157	PC13-eMMC_D5	158	USB1-DP
159	GND	160	USB1-DM
161	HDMI-SCL	162	GND
163	HDMI-SDA	164	HDMI-HPD
165	PC11-eMMC_D3	166	LCD-PWM
167	HDMI-CEC	168	PWR_ON
169	GND	170	NC
171	USB0-DP	172	DCDC1
173	USB0-DM	174	GPIO0-LDO
175	CHG_LED	176	ALDO1
177	RESET	178	
179		180	DCIN
181	ELDO3	182	DCIN
183	DLDO3	184	DCIN
185	VCC-WIFI	186	NC
187	DC1-SW	188	VBUS
189	DLDO2	190	VBUS
191	DLDO1	192	VBUS
193	VCC-WIFI-IO	194	NC
195	VRTC	196	BATT_SENSOR
197	NC	198	NC
199	PS	200	VBAT
201	PS	202	VBAT
203	PS	204	VBAT