Px are Prime number constants
All bus widths are explicitly labeled
External Interface Ports are in Bold
All Clk Ports are tied to External Port **Clk**
All rst ports are tied to External **reset** port unless
otherwise specified