



Kinectic Module Driver Yarp Controller Module Kinect Robot Robot iCub

+getDataFromPort() +sendDataToPort() +addPort() +configureThread() +updateThread() +onPortEvent() TypedReaderCallback

RFModule

Device Interface Driver

+sendDataToPort()

+sendEventToDevice()

+getEventFromDevice()

Device Interface Driver

+getDataFromPort()

+getDataFromPort() +sendDataToPort() +addPort() +configureThread() +updateThread() +sendDataToPort() +getDataFromPort() **Device Interface Driver** RFModule +onPortEvent() +convertDeviceData() +moveRobot(id,angle,speed) motorController +moveRobot(x,y,z,) +updateRobotState() +updateDeviceData() +stopRobot() +startRobot() **iKinContoller**

TypedReaderCallback

#DeviceData

iCubGeneric

+update()

+convertDeviceData()