ENGSCI 233 Lecture 10.1

Computer Architecture

AN x64 PROCESSOR IS SCREAMING ALONG AT BILLIONS OF CYCLES PER SECOND TO RUN THE XNU KERNEL, WHICH IS FRANTICALLY WORKING THROUGH ALL THE POSIX-SPECIFIED ABSTRACTION TO CREATE THE DARWIN SYSTEM UNDERLYING OS X, WHICH IN TURN IS STRAINING ITSELF TO RUN FIREFOX AND ITS GECKO RENDERER, WHICH CREATES A PLASH OBJECT WHICH RENDERS DOZENS OF VIDEO FRAMES EVERY SECOND

BECAUSE I WANTED TO SEE A CAT JUMP INTO A BOX AND FALL OVER.



I AM A GOD.

Today's learning objectives

- Understand and demonstrate breaking a process into computable steps
- Understand the relationship between programming languages, assembly code, and machine code

- Understand the parts of a computer
- Understand processor performance characteristics
- Understand multiprocessor systems

What is a computer anyway?



What is a computer anyway?



Let's run a demonstration.

- 1 volunteer for "memory"
- 1 volunteer for "processor"
- 1 volunteer for "data bus"

Add two large numbers:

12345 + 67890

Demonstration rules:


- One digit per post-it note
- Operations happen in-place if destination is not specified
- The processor can only store 4 digits
 - Everything else goes in main memory
- The processor must tell the data bus what to get from memory

Let's run a demonstration.


- 1. Start with an empty output, zero carry c, and a digit counter k = 0. (Count from the right.)
- Retrieve digit k from each of the numbers to be added.
- 3. Add the digits *k* together, as well as the carry *c*.
- 4. Store the ones digit of the result as digit *k* of the output.
- 5. Replace the value in *c* with the tens digit of the result.
- 6. If $k \le 4$, increment k and go to step 2.
- 7. Display the output.

Computers have four parts.

Processor



Memory



Data transfer




Input and output



Computers have four parts.

These parts could all be on the same silicon chip!



Computer systems add software.

- Operating System
 - Sets standards for access to storage, transport, and I/O
 - Manages multiple programs running together

- Drivers
 - Provide interface between hardware and software.
- We will discuss this more in week 12.

How do programs run on computers?

- Interpreter
 - Software that follows instructions written in code



- Compiler
 - Converts code to machine language to run on its own



An example computer system:



What does code really do?

```
void Commutate (uint16 t *A, uint16 t *B, uint16 t *C, ...
               int16 t Command, uint16 t Position)
       if(Command > PWM IDLE)
               Command = PWM IDLE;
       else if (Command < -PWM IDLE)
               Command = -PWM IDLE;
        *A = 0;
        *B = PWM_IDLE + Command;
        *C = PWM IDLE - Command;
```

- C code
- PWM IDLE is a constant
- Runs on an ARM microcontroller
- How does this compile?

```
C Code
     *B = PWM IDLE + Command;
08005050:
           887b
                        ldrh
                               r3, [r7, #2]
08005052:
         f603 0334
                        addw r3, r3, #2100; 0x834
08005056: b29a
                        uxth r2, r3
08005058:
         68bb
                        ldr r3, [r7, #8]
0800<u>505a</u>: 801a
                        strh r2, [r3, #0]
     *C = PWM IDLE - Command;
0800505c:
           887b
                        ldrh
                               r3, [r7, #2]
0800505e:
         f5c3 6303
                        rsb
                               r3, r3, #2096; 0x830
08005062:
         3304
                        adds r3, #4
08005064:
         b29a
                        uxth r2, r3
08005066: 687b
                        ldr r3, [r7, #4]
08005068:
         801a
                        strh r2, [r3, #0]
```

```
*B = PWM IDLE + Command; Assembly Code
```

```
08005050:
           887b
                       ldrh r3, [r7, #2]
08005052: f603 0334
                       addw r3, r3, #2100; 0x834
08005056: b29a
                       uxth r2, r3
08005058: 68bb
                        ldr r3, [r7, #8]
0800505a: 801a
                       strh r2, [r3, #0]
     *C = PWM IDLE - Command;
0800505c: 887b
                       ldrh r3, [r7, #2]
0800505e: f5c3 6303
                       rsb
                              r3, r3, #2096; 0x830
08005062: 3304
                       adds r3, #4
08005064: b29a
                       uxth r2, r3
08005066: 687b
                        1dr r3, [r7, #4]
08005068:
        801a
                        strh r2, [r3, #0]
```

*B = PWM IDLE + Command; Machine Code

```
08005050: 887b
                       ldrh r3, [r7, #2]
08005052: f603 0334
                       addw r3, r3, #2100; 0x834
08005056: b29a
                       uxth r2, r3
08005058: 68bb
                       ldr r3, [r7, #8]
0800505a: 801a
                       strh r2, [r3, #0]
     *C = PWM IDLE - Command;
0800505c: 887b
                       ldrh r3, [r7, #2]
0800505e: f5c3 6303
                       rsb r3, r3, #2096; 0x830
08005062: 3304
                       adds r3, #4
08005064: b29a
                       uxth r2, r3
08005066: 687b
                       ldr r3, [r7, #4]
                       strh r2, [r3, #0]
08005068:
        801a
```

```
*B = PWM IDLE + Command;
                    ldrh r3, [r7, #2]
08005050: 887b
08005052: f603 0334 addw r3, r3, #2100; 0x834
08005056: b29a
                 uxth r2, r3
08005058: 68bb ldr r3, [r7, #8]
0800505a: 801a strh r2, [r3, #0]
    *C = PWM IDLE - Command;
0800505c: 887b
                    ldrh r3, [r7, #2]
0800505e: f5c3 6303 rsb r3, r3, #2096; 0x830
08005062: 3304
                adds r3, #4
08005064: b29a uxth r2, r3
08005066: 687b
                    ldr r3, [r7, #4]
                 strh r2, [r3, #0]
08005068: 801a
```


```
*B = PWM IDLE + Command;
08005050: 887b
                    ldrh r3, [r7, #2]
08005052: f603 0334 addw r3, r3, #2100; 0x834
08005056: b29a
                 uxth r2, r3
08005058: 68bb ldr r3, [r7, #8]
0800505a: 801a strh r2, [r3, #0]
    *C = PWM IDLE - Command;
0800505c: 887b
                    ldrh r3, [r7, #2]
0800505e: f5c3 6303 rsb r3, r3, #2096; 0x830
08005062: 3304
               adds r3, #4
08005064: b29a uxth r2, r3
08005066: 687b
                    ldr r3, [r7, #4]
              strh r2, [r3, #0]
08005068: 801a
```

```
*B = PWM IDLE + Command;
08005050: 887b
               1drh r3, [r7, #2]
08005052: f603 0334 addw r3, r3, #2100; 0x834
                    uxth r2, r3
08005056: b29a
08005058: 68bb ldr r3, [r7, #8]
0800505a: 801a strh r2, [r3, #0]
    *C = PWM IDLE - Command;
0800505c: 887b
                    ldrh r3, [r7, #2]
0800505e: f5c3 6303 rsb r3, r3, #2096; 0x830
08005062: 3304
               adds r3, #4
08005064: b29a uxth r2, r3
08005066: 687b
                    ldr r3, [r7, #4]
              strh r2, [r3, #0]
08005068: 801a
```

```
*B = PWM IDLE + Command;
08005050: 887b
               1drh r3, [r7, #2]
08005052: f603 0334 addw r3, r3, #2100; 0x834
08005056: b29a
                 uxth r2, r3
                    ldr r3, [r7, #8]
08005058: 68bb
0800505a: 801a strh r2, [r3, #0]
    *C = PWM IDLE - Command;
0800505c: 887b
                    ldrh r3, [r7, #2]
0800505e: f5c3 6303 rsb r3, r3, #2096; 0x830
08005062: 3304
               adds r3, #4
08005064: b29a uxth r2, r3
08005066: 687b
                    ldr r3, [r7, #4]
08005068: 801a
                 strh r2, [r3, #0]
```

```
*B = PWM IDLE + Command;
08005050: 887b
               1drh r3, [r7, #2]
08005052: f603 0334 addw r3, r3, #2100; 0x834
08005056: b29a
                 uxth r2, r3
08005058: 68bb ldr r3, [r7, #8]
                    strh r2, [r3, #0]
0800505a: 801a
    *C = PWM IDLE - Command;
0800505c: 887b
                    ldrh r3, [r7, #2]
0800505e: f5c3 6303 rsb r3, r3, #2096; 0x830
08005062: 3304
               adds r3, #4
08005064: b29a uxth r2, r3
08005066: 687b
                    ldr r3, [r7, #4]
               strh r2, [r3, #0]
08005068: 801a
```

What does the processing?



Semiconductor chips!

 May use many computing units in parallel on one or many separate chips

Processor performance varies.

How many bits?


What kinds of instructions?

How many instructions per second?






Multiple processors add challenges.



- Processors stopped getting faster in 2010
 - Still getting smaller and cheaper!
- Multiple programs at once
 - The OS handles it.
- Parallel processing
 - Your job!

GPUs have thousands of processors.

- 3D graphics requires a lot of math
- A GPU is optimized for math
 - >1000 processor cores
 - Many operate in lockstep
 - Simple instruction set
- Limited performance memory interface



Supercomputers have even more.



- Combination of thousands of ordinary desktop CPUs and GPUs
- >2,000,000 processor cores at the top end
- Requires special software

Next time: Storage and transport

Image References

```
Slide 1: Abstraction, by Randall Munroe, from https://xkcd.com/676/ (CC BY-NC 2.5)
Slide 3 (top left): by LG전자, from https://commons.wikimedia.org/wiki/File:Inductive charging of LG smartphone (2).jpg (CC
BY 2.0)
Slide 3 (top centre): by Raimond Spekking, from
https://commons.wikimedia.org/wiki/File:Lenovo G500s laptop-2905.jpg (CC BY-SA 4.0)
Slide 3 (top right): by Gareth Halfacree, from https://www.flickr.com/photos/120586634@N05/26212930836
(CC BY-SA 2.0)
Slide 3 (bottom): from https://www.nesi.org.nz/services/high-performance-computing/platforms (UoA copyright)
Slide 4: from http://sites.harvard.edu/~chsi/markone/about.html
Slide 8 (top left): by Gregg M. Erickson, from https://commons.wikimedia.org/wiki/File:Motorola68040die.jpg (CC BY 3.0)
Slide 8 (top right): by Maurizio Pesce, from <a href="https://commons.wikimedia.org/wiki/File:USB">https://commons.wikimedia.org/wiki/File:USB</a> Type-C macbook.png (CC BY 2.0)
Slide 8 (bottom left): by Daniel Sancho, from https://commons.wikimedia.org/wiki/File:8 bytes vs. 8Gbytes.jpg (CC BY 2.0)
Slide 8 (bottom right): by Zzubnik, from https://commons.wikimedia.org/wiki/File:Computer monitor.jpg (Public domain)
Slide 9: from https://web.archive.org/web/20140414084027/http://blog.ioactive.com/2007 11 01 archive.html
Slide 13: by Jonathan Joseph Bondhus, from https://commons.wikimedia.org/wiki/File:Stack of Copy Paper.jpg (CC BY-SA 3.0)
Slide 14: by Perplexeus, from <a href="https://commons.wikimedia.org/wiki/File:Haystack.png">https://commons.wikimedia.org/wiki/File:Haystack.png</a> (CC BY-SA 4.0)
Slide 22: by Gregg M. Erickson, from https://commons.wikimedia.org/wiki/File:Motorola68040die.jpg (CC BY 3.0)
Slide 23 (top): from https://www.anandtech.com/show/13910/intels-core-i9-9900kf-listed-in-the-usa-582-usd
Slide 23 (bottom): from https://electronics.stackexchange.com/a/84851
Slide 24 (top): by AMD, from https://commons.wikimedia.org/wiki/File:AMD Phenom die equalized.png (freely licensed)
Slide 24 (bottom): by Érick Luiz Wutke Ribeiro, also known as: Delemon, from https://commons.wikimedia.org/wiki/File:Cell-
```

Slide 25: from https://www.extremetech.com/gaming/272764-new-amd-gpu-rumors-suggest-polaris-refresh-in-q4-2018 Slide 26: from https://www.extremetech.com/gaming/272764-new-amd-gpu-rumors-suggest-polaris-refresh-in-q4-2018 Slide 26: from https://www.extremetech.com/extreme/146967-stanford-breaks-million-core-supercomputing-barrier2

Processor.jpg (CC BY 3.0)