

RC / RL / RLC
RC / RL
1st order system
2nd order
Generally,
If only one of L/C present ⇒ 1st order
If both L & C present ⇒ 2nd order
2-roots
1-real
phase diff 1
phase diff 2
harmonic ⇒ s² will appear!

Diffrential eqn view

$$V_c(s) = \frac{A}{s^2 + as + b}$$

$$\left(s^2 + as + b\right) V_c(s) = A$$

$$s^2 V_c(s) + a\left(sV_c(s) + bV_c(s) = A - aV_c(0)\right.$$
$$\left. - V_c(0)\right)$$

$$s\left(sV_c(s)\right) + a\left(\frac{dv_c}{dt} + V_c(0)\right) = \left(A - aV_c(0)\right)\delta(t)$$

$$\frac{d}{dt}\left(\;\right) + \left(\;\right)_{t=0}$$

$$\mathcal{L}^{-1}\left(sF(s)\right) \Rightarrow \frac{df}{dt} + f(0)$$

$$\frac{df}{dt} \xrightarrow{\mathcal{L}} sF(s) - f(0)$$

$$\mathcal{L}^{-1}\left(sF(s) - f(0)\right) \Rightarrow \frac{df}{dt}$$

$V_c(0) = 0 \quad \frac{dv_c}{dt}(0) = 0$

$$\frac{d^2 V_c(t)}{dt^2} + a\frac{dv_c}{dt} + bV_c(t) = C$$

2-nd order diff eqn

$$V_c(s) = \frac{A}{s+a}$$

Domain change

$\Rightarrow$ diff eqn order 1.


$$\Rightarrow \quad sV_c(s) + aV_c(s) = A$$

$\mathcal{L}^{-1}$

$$\Rightarrow \quad \frac{dv_c(t)}{dt} + aV_c(t) = A\delta(t)$$

1-st order diff eqn !

Series RLC




$V_c(t)$

KVL (s-domain) $\Leftarrow$

KVL in time domain using $C\frac{dv_c}{dt}$ $\Leftarrow$ $\frac{d}{dt}(\;)$

$$V_c(t) + i(t) \cdot R + L\frac{di(t)}{dt} = 0$$



$$V_c(t) + R \cdot C\frac{dv_c}{dt} = 0$$

1st order

$$R \cdot i(t) + L \cdot \frac{di(t)}{dt} = 0$$

$$q(t) = C \cdot V_c(t)$$

$$i(t) = \frac{dq(t)}{dt} = C\frac{dv_c(t)}{dt}$$

$$\frac{di(t)}{dt} = C\frac{d^2 V_c(t)}{dt^2}$$

$$C\frac{d^2 V_c(t)}{dt^2}$$

$V_C(t) = \frac{1}{C}\int_0^t i(t)\,dt$ $\quad q(0) = 0$

$i(t) = \frac{dq}{dt}$ $\quad q(t)$

$V_L(t) = L\,\frac{di(t)}{dt}$

double derivative

KVL

C $\quad$ L $\quad$ $q(t)$ $\quad$ Same der of $V_C(t)$ $\quad$ $\frac{dV_C}{dt}$ Res $\quad$ $\frac{d^2q}{dt^2}$

$\frac{d^2q(t)}{dt^2} + b\frac{dq(t)}{dt} + bx(t)$

$\frac{d^2V_C(t)}{dt^2} + \frac{dV_C(t)}{dt} = 0$

Subst $x(t) = \frac{dV_C}{dt}$ $(i(t)$

1st order

PSS

Recall RLC (series & parallel)

→ 2nd order

$V_C(t)$

$V_C(0) = V$

KCL currents sum to 0 (s-domain seen before)

from Cap $\quad q(t) = CV_C(t)$

$i_C(t) = C\frac{dV_C}{dt}$

$i_R(t) = \frac{V_C(t)}{R}$ ← Ohm's

$V_L(t) = L\frac{di_L(t)}{dt}$

PSC

KCL $\quad i_L(t) + i_C(t) + i_R(t) = 0$

$i_L(t) = \int_0^t \frac{V_C(t)}{L}\,dt$ $\quad$ derivative ← integro-diff eqn

Diff KCL $\quad \frac{di_L}{dt} + \frac{di_C(t)}{dt} + \frac{di_R(t)}{dt} = 0$

$\frac{V_C(t)}{L} + C\frac{d^2V_C}{dt^2} + \frac{1}{R}\frac{dV_C(t)}{dt} = 0$

Damping factor

$\xi = \frac{1}{2Q}$

$\xi < 1 \Rightarrow$ under

$\xi > 1 \Rightarrow$ over

ω $\quad T$

osc in $\frac{T}{}$ (scaled $\zeta 2\pi$)

Quality factor (Q)

(RLC circuit) $\quad$ (2π) number of osc before dissipation

series ↘ parallel


$Q = \gamma \cdot \omega$ $\quad$ time const $\quad$ Series $\frac{L}{R}$ parallel RC

natural freq $\quad \frac{1}{\sqrt{LC}}$ (skunk pic)

$R = 0 \Rightarrow Q = \infty$

$Q > \frac{1}{2}$: Under

$Q < \frac{1}{2}$ overdamp


Source tran =>
Does NOT always work (some complicated circuits cannot be simplified)
(NOT universal)
Source tran
dep source depends on R
in such cases
only option do nodal/mesh analysis
VCCS
Do Thevenin
unstable