EE2707 ANALOG SYSTEMS LAB

INSTALLING MISSING LTSPICE COMPONENTS:

1. **Access the provided Drive link to download the required component files.**
2. **Copy the symbol and library files into your local LTspice sym folder.**
3. **The missing components will subsequently appear in the application's component list.**

COMPONENTS USED IN SIMULATION:

EXPERIMENT 1

- OPA1: MCP 6004(Model MCP6001)
- CMP1 and CMP2: LM 339

EXPERIMENT 2

- Gate Drivers:
  - LTC 1693-1 (present in LTspice)
- Logic Gates:
  - NAND: SN74HCOON
  - Inverter: CD4069UBE
- Power FETs:
  - NMOS: NTMFS5C646NLA
  - PMOS: Si4427DY

EXPERIMENT 3

- OPA2: MCP 6004(Model MCP6001)
- LED: L128-FRD 1003500000

EXPERIMENT 4

- CMP1 and CMP2: LM 339
- Inverter: CD4069UBE

EE2707 ANALOG SYSTEMS LAB

EXPERIMENT 5

- Logic:
  - Inverter: CD4069UBE
  - NAND: SN74HCOON
- CMP1 and CMP2: LM339
- BJTs:
  - IN2902 (pnp)
  - IN2222 (npn)

EXPERIMENT 6

- OPA: MCP 6004(Model MCP6001)

EXPERIMENT 7

- OPA: MCP 6004(Model MCP6001)
- Diode: 1N4148 (General purpose)

DRIVE LINK FOR THE COMPONENTS:

HTTPS://DRIVE.GOOGLE.COM/DRIVE/FOLDERS/1NVAJEPUZHTCC0_6_N_0FHEJRDUIC1ZSX

Link for labmanual:

https://www.ee.iitm.ac.in/vlsi/_media/courses/ee2019_2024/analog_system_lab_2024.pdf