

BIN BAY SCREEN HOARDING - BUILDER'S BRIEFING

Ref TW-BINS-001 Rev P01 4 October 2026 One page. Full details on the drawings.

NOT A DESIGN - NOT FOR CONSTRUCTION - NOT A PERMIT TO LOAD

NOT A DESIGN and NOT FOR CONSTRUCTION. The temporary works designer owns the design and its independent check. Do not start until a permit to load has been issued.

WHAT YOU ARE BUILDING

A 2.40 m high screen hoarding round the bin bay: a 6.00 m front run with a 1.20 m return at each end back to the building wall. 75 x 225

C24 posts, 100 x 75 C24 rails laid flat, 18 mm OSB/3 facing on the outside, and a 1.20 x 2.10 m gate so the bins can be wheeled out.

SETTING OUT - DO THIS FIRST

- String a line for the front run. Posts at 2.00 m centres: P1 at 0.00, P2 at 2.00, P3 at 4.00, P4 at 6.00.
- Returns run 1.20 m back from each end: P5 from P1, P6 from P4. Check the diagonals before you fix anything - a racked hoarding is a failed hoarding.
- Set out from the left return. Total run 8.40 m.

BUILD SEQUENCE

1. Break out and dig 6 holes, 400 mm diameter x 900 mm deep, one per post. Confirm the tarmac may be broken out and the services are clear.
2. Stand the posts in the holes, plumb in both directions, brace them so they cannot move, then fill with mass concrete full depth.
3. Leave the concrete to go off. Do not load the posts until it has.
4. Fix the rails to the OUTSIDE face at 0.225, 1.200, 2.300 m centres - three levels, between adjacent posts, front run and both returns.
5. Fix the 18 mm OSB/3 to the rails on the outside, vertical, joints over a rail, sheets cut to suit. Butt them tight.
6. Hang the gate last, on post P2, with a keep and sliding bolt on P3. Check it swings clear of the ground and latches.
7. Clear up. No arisings against the hoarding.

CALL OFF

- 75 x 225 C24 treated post x 2.40 m long - 7 no. (6 required)