

TEMPORARY HALF-PIPE RAMP - BUILDER'S BRIEFING

Ref TW-HP-001 Rev P01 4 October 2026 One page. Full details on the drawings.

NOT A DESIGN - NOT FOR CONSTRUCTION - NOT A PERMIT TO LOAD

NOT A DESIGN and NOT FOR CONSTRUCTION. The temporary works designer owns the design and its independent check. Do

not erect, ballast or let anyone ride it until a permit to load has been issued.

WHAT YOU ARE BUILDING

A temporary half-pipe 20.00 m long with 5.00 m of riding surface: a 1.00 m flat bottom between two 2.00 m transitions, coping 2.00 m high, 0.60 m decks behind each coping, 6.20 m overall. Timber framing, 24 mm ply surface in two layers, closed sides.

SETTING OUT - DO THIS FIRST

- Set out the 20.00 m length and the 6.20 m width. Check the diagonals.
- Mark the coping lines and the 1.00 m flat bottom, then mark every cross frame at 1.20 m centres - 18 of them.
- Set the flat bottom and the two transitions out with a trammel from the transition centres. A transition that is not a true arc will ride badly and will be rejected.

BUILD SEQUENCE

1. Spreader pads first, 450 x 450, under every leg. Legs are 100 x 100 C24 and their height follows the transition - do not cut them all the same length.
2. Fix the longitudinal bearers, then the curved ribs at 1.20 m centres. Check every arc against the trammel before you board over it.
3. Lay the 24 mm surface in two layers, screwed at 150 mm centres, joints staggered between layers and landing on a rib.
4. Fix the coping tube along both top edges, then the decks.
5. Close the ends and the sides with 18 mm ply. Nothing must be reachable inside the structure - that is both a safety point and how the wind check assumes it behaves.
6. Ballast last, to the design quantity and position. Do not ride it before that is done and signed off.

CALL OFF

- Leg 100 x 100 C24 treated, average 1.50 m - 36 no