

Date: TBD

## **COSMOS Command and Telemetry Handbook**

For the COSMOS Demo Project



### Document No.: XXXXXXX

Revision: TBD Date: TBD

#### **Table of Contents**

Table of Contents	2
Commands	3
COSMOS STARTCMDLOG	3
COSMOS STARTLOGGING	3
COSMOS STARTTLMLOG	3
COSMOS STOPCMDLOG	3
COSMOS STOPLOGGING	4
COSMOS STOPTLMLOG	4
Telemetry Packets	4
COSMOS LIMITS_CHANGE	4
COSMOS VERSION	5



Date: TBD

## Commands

## **COSMOS STARTCMDLOG**

Starts logging commands for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	44983810	9 44983810	9 449838109	9 0	32	UINT	
OPCODE	COSMOS Command Opcode  Id Value: 3	3	3	3	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to start logging on - ALL starts logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

#### **COSMOS STARTLOGGING**

Starts logging both commands and telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	44983810	9 44983810	9 449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode Id Value: 2	2	2	2	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to start logging on - ALL starts logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

#### **COSMOS STARTTLMLOG**

Starts logging telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode  Id Value: 4	4	4	4	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to start logging on - ALL starts logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

#### **COSMOS STOPCMDLOG**

Stops logging commands for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109 4	49838109	449838109	0	32	UINT	



vision: IBD Date: TBD

OPCODE	COSMOS Command Opcode Id Value: 6	6	6	6	32	32	UINT
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT
INTERFACE	Interface to stop logging on - ALL stops logging on all interfaces			ALL	96	256	STRING
LABEL	Optional label to place on log files				352	0	STRING

#### **COSMOS STOPLOGGING**

Stops logging both commands and telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	44983810	9 449838109	9 449838109	9 0	32	UINT	
OPCODE	COSMOS Command Opcode  Id Value: 5	5	5	5	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to stop logging on - ALL stops logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

#### **COSMOS STOPTLMLOG**

Stops logging telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	44983810	9 44983810	9 449838109	0 0	32	UINT	
OPCODE	COSMOS Command Opcode  Id Value: 7	7	7	7	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to stop logging on - ALL stops logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

# **Telemetry Packets**

### COSMOS LIMITS\_CHANGE

COSMOS limits change

OCCIVIOU IIIIIIS CHANGE						
Item Name	Description	Bit Offset	Bit Size	Data Type	Units Format	
RECEIVED_TIMESECONDS	COSMOS Received Time (UTC, Floating point, Unix epoch)	0	0	DERIVED	%0.6f	
	Read Conversion: ReceivedTimeSecondsConversion					
RECEIVED_TIMEFORMATTED	COSMOS Received Time (Local time zone, Formatted string)	0	0	DERIVED		
	Read Conversion: ReceivedTimeFormattedConversion					
	COSMOS packet received count					



Date: TBD

RECEIVED_COUNT	Read Conversion: ReceivedCountConversion	0	0	DERWED
PKT_ID	Packet ID Id Value: 2	0	8	UINT
TARGET	Target name	8	240	STRING
PACKET	Packet name	248	240	STRING
ITEM	Item that changed limits state	488	240	STRING
OLD_STATE	The old limit state	728	240	STRING
NEW_STATE	The new limit state	968	240	STRING

## **COSMOS VERSION**

COSMOS version information

Item Name	Description	Bit Offset	Bit Size	Data Type	Units Format
RECEIVED_TIMESECONDS	COSMOS Received Time (UTC, Floating point, Unix epoch)	0	0	DERIVED	%0.6f
	Read Conversion: ReceivedTimeSecondsConversion				
RECEIVED_TIMEFORMATTED	COSMOS Received Time (Local time zone, Formatted string)	0	0	DERIVED	
	Read Conversion: ReceivedTimeFormattedConversion				
DECEMED COUNT	COSMOS packet received count	0	0		
RECEIVED_COUNT	Read Conversion: ReceivedCountConversion	0	0	DERIVED	
PKT_ID	Packet ID Id Value: 1	0	8	UINT	
COSMOS	COSMOS version	8	240	STRING	
RUBY	Ruby version	248	240	STRING	
CTDB	Command Telemetry Database Version	488	240	STRING	
USER	User Version	728	240	STRING	