
Digital Arts presents

Digital Display

Make your TV a new way to advertise.

Turn any Android TV into a digital signboard. Upload photos and videos from your phone and they play on your TVs in seconds, with your logo, offers, clock and QR code.

Any Android TV · Control from your phone · Works offline · Remote lock



display.datpl.com
Features · Plans · Installation guide

INSIDE

1 · What it is 2 · Features 3 · Plans
4 · Installation: TV, phone, computer 5 · Help

1 · WHAT IS DIGITAL DISPLAY

Your TV, your advertising screen

Digital Display is digital signage made simple for shops, restaurants, hotels, clinics, gyms and offices. You manage everything from a website on your phone or computer — the TV app just plays.

1

Install the TV app

Download the app on any Android TV or TV box from **display.datpl.com/app**. The TV shows a 6-digit code.

2


Link the TV

Log in at **display.datpl.com** on your phone, type the code (or scan the QR on the TV) and give the TV a name.


3

Upload & play

Upload photos and videos, add them to a playlist and press Save. The TV changes within 20 seconds.



The dashboard on a computer: your TVs, photos & videos and playlist on one page



What your customers see on the TV: your ad with clock, QR code, caption and a scrolling offer line

Made for

Retail & fashion stores · Restaurants & cafés · Hotels & reception · Clinics & hospitals · Gyms & salons · Showrooms · Schools & coaching · Offices & lobbies · Banquet halls

No extra hardware

Use the Android TV you already have (Android 5 or newer), or a low-cost Android TV box on any TV with HDMI. No media player, no pen drives, no cables to your computer.

Change content from anywhere

Sitting at home or travelling, open display.datpl.com on your phone, change the offer and press Save. Every TV in every branch updates by itself.

2 · FEATURES

Everything a shop screen needs

Simple enough for anyone at the counter, powerful enough for a chain of branches.

Any Android TV

Android TV, Google TV and Android TV boxes. Any screen with a web browser can also play.

Link with a code

The TV shows a 6-digit code and QR code. Type or scan it once — no passwords on the TV.

Photos & videos

Upload JPG, PNG and MP4 (up to 50 MB each) from phone or computer. Folders become captions.

Playlists

Several playlists — e.g. "Main" and "Weekend offers" — and a different one on each TV. Drag to reorder.

Ads & schedule

Play an ad after every few items or at fixed times, only on chosen dates, days or hours.

Your branding

Logo, clock with date, QR code (e.g. WhatsApp), captions and a scrolling offer line in your colour.

Welcome screen

Greet guests or clients by name — "Welcome Mr Sharma, ABC Ltd" — until a time you choose.

Layout editor

Drag the logo, clock, QR and ticker where you want them. 16:9, 4:3, 21:9, portrait or a custom size.

Works offline

The TV keeps a copy of your playlist and keeps playing when the internet goes down.

Starts with the TV

"Open with the TV" makes Digital Display come up by itself after power-on or standby.

Remote lock + PIN

Staff can't close the app with the remote. A 4-digit PIN from your dashboard unlocks it in an emergency.

ON / OFF from your phone

Switch the display off and the TV goes back to its normal home screen; switch it on again any time.

Live TV status

See which TVs are on right now, their screen size and app version, and which account they belong to.

Automatic updates


The TV app checks for new versions by itself; the player updates without reinstalling.

Secure cloud


Your files are stored in the cloud, private to your account. Log in with email and password.

2 · FEATURES IN PICTURES


See it in action



TV Preview & layout editor — drag the clock, QR code, caption and ticker; what you see is what the TV shows



Press ▼ on the remote: which account, business and playlist this TV runs



A new TV shows its code and a QR code to link it

Remote ON / OFF and lock

Every TV card in the dashboard has a **Display ON / OFF** button and its **PIN**.

- **OFF:** within ~30 seconds Digital Display closes and the TV shows its own home screen.
- **ON:** within ~30 seconds Digital Display opens again.
- While ON, the remote's BACK, TV and Home buttons can't leave the display.
- Emergency: on the TV hold OK › **Unlock with PIN**.

3 · SUBSCRIPTION PLANS

Simple pricing, per TV

Every plan includes the TV app, the dashboard, cloud storage and free updates. Start with a **14-day free trial** — no card needed. Pay yearly and get **2 months free**.

Starter

For a single shop or café with one or two screens

₹299 / TV / month

₹2,990 / TV / year

- Up to 2 TVs
- 2 GB cloud storage
- 1 playlist
- Photos & videos (MP4)
- Logo, clock, captions, scrolling offer line
- Works offline · starts with the TV
- Remote lock, PIN, ON / OFF from phone
- Support on WhatsApp

MOST POPULAR

Business

For busy stores, restaurants, hotels and clinics

₹549 / TV / month

₹5,490 / TV / year

- Up to 10 TVs
- 10 GB cloud storage
- Unlimited playlists, one per TV
- Ads & schedule by date, day and time
- QR code & welcome screen for guests
- Layout editor & all screen sizes
- Everything in Starter
- Priority WhatsApp support

Enterprise

For chains, malls and multi-branch businesses

₹899 / TV / month

₹8,990 / TV / year

- Unlimited TVs & branches
- 50 GB cloud storage
- Everything in Business
- Help with setting up every TV
- Dedicated account manager
- Team members & roles (coming soon)
- Proof-of-play reports (coming soon)
- TV groups by branch (coming soon)

Compare	Starter	Business	Enterprise
TVs	up to 2	up to 10	unlimited
Cloud storage	2 GB	10 GB	50 GB
Playlists	1	unlimited	unlimited
Photos, videos, logo, clock, ticker	✓	✓	✓
Offline play, auto-start, lock, PIN, ON/OFF	✓	✓	✓
Ads & schedule	—	✓	✓
QR code, welcome screen, layout editor	—	✓	✓
Setup help for every TV · account manager	—	—	✓

14-day free trial
All Business features, no card needed.

Yearly = 2 months free
Pay for 10 months, use 12.


Prices exclude GST
Cancel any time; content stays until the plan ends.

A Install the app on the TV


You need: an Android TV, Google TV or Android TV box (Android 5 or newer), Wi-Fi or a LAN cable, and the TV remote. Takes about 5 minutes.

1. **Allow apps from outside the Play Store.** On the TV open **Settings › Device Preferences › Security & restrictions › Unknown sources** and turn it on for the browser (the menu names differ a little between TV brands — look for "Unknown sources" or "Install unknown apps").
2. **Download the app.** Open the TV's browser (or the free "Downloader" app) and type `display.datpl.com/app`. The file **DigitalDisplay.apk** downloads.
3. **Install.** Open the download and press **Install**, then **Open**.
   No browser on the TV? Copy the APK to a pen drive on your computer, plug it into the TV and open it with the TV's file manager.
4. **Note the code.** The TV now shows **Digital Display** with a 6-digit TV code and a QR code. Leave it on this screen and link it from your phone (next page).
5. **Let it start with the TV.** When the app asks "Start with the TV?", press **OK** and allow **Display over other apps** for Digital Display. On older TVs the app offers "Open Digital Display with the TV?" — choose **Yes**, then Digital Display › **Always**.

> **Updates:** the app checks for new versions by itself. To update now, hold **OK** for 2 seconds › **Check for updates** › Install.




Step 4 — the TV shows its code




Hold OK for 2 seconds to open the app menu (photo from a real TV)

B On your phone: account, link TV, add photos


Nothing to install on the phone — Digital Display runs in Chrome or Safari. Tip: in the browser menu choose **Add to Home screen** to get an app icon.



1 · Create an account / log in



2 · My TVs — link a TV with its code



3 · Upload photos & videos, add to playlist

Create your account

1. Open `display.datpl.com` and tap **New here? Create an account**.
2. Enter your business name, email and a password. Open the confirmation link we email you, then **Log in**.

Link the TV

1. In **My TVs › + Add a TV** type the 6-digit code shown on the TV and a name, e.g. "Reception".
2. Tap **Link TV**. Or simply scan the QR code on the TV with your phone camera — the code fills in by itself.


Put your ads on the TV

1. In **My photos & videos** tap **Choose files**. Optional: a folder name, shown as the caption.
2. Tap **+ Playlist** on each file, or **+ Add all**.
3. Tap **Save** at the top. The TV changes within 20 seconds.

> **Videos:** use MP4. iPhone videos (.mov) and HEIC photos often don't play on TVs — on iPhone choose Settings › Camera › Formats › **Most Compatible**.

C On a computer

Open `display.datpl.com` in Chrome, Edge or Firefox and log in with the same account. Everything you do on the phone works here too — with more room.



The dashboard: My TVs (top), My photos & videos (left), Playlist (right). Further down: logo, clock, QR, ticker, welcome screen, ads & schedule.

Useful on a computer

1. **Drag & drop** many photos and videos at once onto the upload box.
2. **TV Preview** (top right) shows exactly what the TV will show, and lets you drag the clock, logo and QR code into place.
3. **Save** sends the changes to all TVs using this playlist.

Use a computer or monitor as the display

1. On the computer connected to the screen, open `display.datpl.com/tv` in Chrome.
2. Press **F11** for full screen. Link the code shown, as for a TV.
3. Keep the computer from sleeping (Windows: Settings › Power › Screen and sleep › Never).

> The TV app is better for a TV: it starts by itself, locks the remote and can be switched on/off from your phone.

5 · DAILY USE & HELP

Lock, ON/OFF and quick fixes

The lock on the TV

Once a TV is linked, it is locked: the remote can't close Digital Display, open TV settings or switch apps — the TV and Home buttons bring the display back within a couple of seconds.

To use the TV normally: tap **Display OFF** on the TV's card in the dashboard. To change app settings on the TV: hold `OK` › **Unlock with PIN** (the PIN is on the TV's card) — the full menu opens for 5 minutes.

The remote

`OK` held 2 s — app menu (info, reload, updates, unlock)
`▼` — which account and playlist this TV runs
`MENU` — app menu on remotes that have it

Removing a TV from the dashboard unlinks it: the TV shows a new code and is unlocked.

Quick fixes

TV shows "Playlist is empty"	Add files to the playlist the TV plays (My TVs › Plays) and press **Save**. Check you are logged in to the account the TV belongs to (press ▼ on the TV).
A video is skipped	Convert it to MP4 (H.264). .mov and HEIC files often don't play on TVs.
TV dot is grey in the dashboard	The TV is off or offline. It keeps playing its saved copy and catches up when the internet is back.
App doesn't start after power-on	Unlock with PIN › turn on **Open with the TV**, and allow **Display over other apps** for Digital Display in the TV's settings.
"Update available" on the TV card	On the TV hold OK › **Check for updates** › Install. Or download again from display.datpl.com/app.
Forgot the password	On the login page tap **Forgot password?** and follow the email.

Need help? WhatsApp **+91 99332 11177** · more software at **apps.datpl.com**



Start your free trial

14 days, all Business features, no card needed.

display.datpl.com

TV app: **display.datpl.com/app**

WhatsApp: **+91 99332 11177**

More software from Digital Arts: **apps.datpl.com**

Prices and features may change; plan limits apply from launch of billing.