


Revision 08.02.18



### **Controls**

- **Fuzz** Controls the amount of fuzz
- **Swell** Controls the overall output volume
- Filter Controls input frequency range
- **Bias** Sets the idle bias current

All trademarks and registered trademarks are the property of their respective owners. The company, product, and service names used in this web site are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.



# Kilimanjaro Fuzz

Parts List

RESISTORS	
R1	1M
R2	1M
R3	4K7
R4	220K
R5	2K2
R6	33K
R8	15K
R9	15K
R10	56K
R11	1M
R100	4K7

CAPACITORS	
C1	1n
C2	22u
C3	100n
C4	82n
C5	100n
C100	10u
C101	22u

TRANSISTORS	
Q1	OC75
Q2	CV7004
Q3	OC75


## INTEGRATED CIRCUITS IC100 TC1044SCPA


**DIODES**D100 1N5817

**POTENTIOMETERS** FUZZ A50K

FUZZ A50K FILTER B100K SWELL A500K

TRIM POTS (3362P) BIAS 10K








# Kilimanjaro Fuzz

Wiring Diagram





**Kilimanjaro Fuzz**Drill Template
125B enclosure with top mounted jacks

