


Revision 06.23.20



Controls

- Volume
- Gain
- Bass
- Treble
- Gain Range (Toggle Switch)
- Clipping Mode (Internal Switch)

All trademarks and registered trademarks are the property of their respective owners. The company, product, and service names used in this web site are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.




Tommy III Parts List

RESISTORS (1/4W)		CAPACITORS		INTEGRATED CIRCUITS	
R1	1M	C1	39n	IC1	LM1458N
R2	1M	C2	100p		
R3	3K3	C3	39n	DIODES	
R4	3K3	C4	820n	D1	1N4148
R5	18K	C5	6n8	D2	1N4148
R6	3K3	C6	820n	D3	1N4148
R7	3K3	C7	47u	D4	1N4148
R8	8K2	C8	47u	D7	1N5817
R9	10K	C9	220n		
R10	4K7	C10	100p	POTENTIOME	TERS .
R11	2K2	C11	6n8	VOL	A25K
R12	360R			GAIN	A500K
R13	2K2			BASS	C50K
				TREBLE	C50K

SWITCHES

SPDT Mini Slide (ESP1010) SW1

SW2 DPDT (On/On)





Tommy III Wiring Diagram

