


Revision 11.06.19



Controls

- Fuzz
- Voice
- Level

All trademarks and registered trademarks are the property of their respective owners. The company, product, and service names used in this web site are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.



Kinetic Fuzz

Parts List

RESISTORS (1/4W)		
R1	1M	
R2	100K	
R3	100K	
R4	220K	
R5	33K	
R6	15K	
R7	22K	
R8	510K	
R9	47K	
R10	47R	
R11	3K3	
R12	470K	
R13	1K2	
R14	5K6	
R15	8K2	
R16	100K	
R17	10K	
R18	1K5	
R100	4K7	
R101	220K	

R102 220K

CAPACITORS		
C1	220n	
C2	470n	
C3	10n	
C4	1n	
C5	10u	
C6	1u	
C7	220p	
C8	1u	
C9	100n	
C10	120n	
C11	1u	
C12	1u	
C13	100n	
C100	100u	
~	4.0	

C101 10u


TRANSISTORS Q1 AC187

INTEGRATED CIRCUITS IC1 TL072 IC2 TL072

DIODES		
D1	3mm Red	
D2	3mm Red	
D3	1N34A	
D100	1N5817	

POTENTIOMETERS		
FUZZ	A50K	
VOICE	B10K	

LEVEL A10K



PedalPCB



Kinetic Fuzz

Wiring Diagram





Kinetic Fuzz

Drill Template 125B Enclosure

