


Revision 06.24.18



Controls

- **Volume** Controls the overall output volume
- Attack Controls the amount of fuzz



Tone Vendor MKII


Parts List


ATTACK B1K

LEVEL

A100K

RESISTORS		CAPACITORS		TRAN	TRANSISTORS	
R1	100K	C1	10n	Q1	OC81D	
R2	10K	C2	100n	Q2	OC81D	
R3	470	C3	5u	Q3	OC81D	
R4	100K	C4	10n			
R5	100K	C5	10u	INTEGRATED CIRCUITS		
R7	8K2	C6	47u	IC1	TC1044SCPA	
R10	4K7	C7	5u			
				DIODES		
				D1	1N5817	
				POTENTIOMETERS		








Tone Vendor MKII

Wiring Diagram





Tone Vendor MKII

Drill Template

125B enclosure with top mounted jacks

