## **Address Table and Command Table for Slim Remote Control Unit**

Dip switch 1	Dip switch 2	Address bits
OFF	OFF	0BH
ON	OFF	0FH
OFF	ON	19H
ON	ON	1CH

Key	Command bits
1	00H
2	01H
3	02H
4	03H
5	04H
6	05H
7	06H
8	07H
9	08H
10	09H
11	32H
12	33H
13	34H
14	35H
15	36H
16	37H