EasyEDA Pro keyboard shortcuts

The ones you'll use every day

Default keys for the online editor at pro.easyeda.com/editor. The full list is on the back.

Both editors

Scroll wheel	Zoom in and out
Hold right button	Pan the view
K	Fit everything on screen
Esc	Stop the current tool (right-click works too)
Space	Rotate the selected or placing object
Tab	Edit properties while placing
Hold Shift	Keep lines straight while drawing
Ctrl + Z	Undo
Ctrl + Y	Redo
Ctrl + S	Save all
S	Show or hide the bottom panel
Q	Switch units (mm / mil)
H	Highlight a net (Shift+H clears it)

Schematic

Shift + F	Place a device (part search)
W	Draw a wire
N	Place a net label
T	Add text
Page Down	Next sheet, or a new one

PCB

W	Route a track[1]
L	Change corner style while routing
Shift + W	Cycle preset track widths while routing
Backspace	Remove the last track segment
V	Place a via
T	Work on the top layer
B	Work on the bottom layer
Shift + B	Rebuild all copper pours
Shift + M	Hide or show copper pours
Alt + M	Measure a distance

Where is that command?

Start a project	File › New › Project
Send the schematic to the PCB	Design › Update/Convert Schematic to PCB
Bring later schematic edits across	Design › Import Changes from Schematic
Check for errors (both editors)	Design › Check DRC
Set track widths and spacing	Design › Design Rule
Draw the board edge	Place › Board Outline
Add a ground pour	Place › Copper Pour Area
See the board in 3D	3D button on the top toolbar
Files for the factory	Export › PCB Fabrication File (Gerber)
Parts list	Export › Bill of Materials (BOM)
Assembly positions	Export › Pick and Place File
Printable schematic	Export › PDF/Image
Order boards	Order › PCB Order
View or change any shortcut	Settings › Shortcut Keys

[1] Some setups route with Alt + W instead of W. [2] Zoom keys may be unassigned by default; the scroll wheel always works. Any key can be changed in Settings › Shortcut Keys, so a shared computer may differ.

EasyEDA Pro: designing a PCB		Rev A
Title: Everyday shortcuts	Source: EasyEDA Pro docs	Sheet: 1 of 2

Every default shortcut

Grouped by what you're doing

From the official EasyEDA Pro shortcut reference:
prodocs.easyeda.com/en/introduction/hotkeys

Files, tabs and help

Shift + N	New project
Ctrl + O	Open project
Ctrl + S	Save all
Ctrl + Shift + S	Save current document
Shift + W	Close current tab
Shift + Alt + W	Close all tabs
Ctrl + Shift + ←	Open in a new window
F11	Full screen
F1	Open the help docs

View

A	Zoom in[2]
Z	Zoom out[2]
K	Fit all
← → ↑ ↓	Scroll the view
Page Up	Previous page
Page Down	Next page, or new page
S	Bottom panel on or off
Q	Switch units
H	Highlight net
Shift + H	Cancel highlight

Align and distribute

Ctrl + Shift + L	Align left
Ctrl + Shift + R	Align right
Ctrl + Shift + O	Align top
Ctrl + Shift + B	Align bottom
Shift + Alt + E	Center left to right
Shift + Alt + H	Center top to bottom
Ctrl + Shift + H	Distribute across
Ctrl + Shift + E	Distribute down
Ctrl + Shift + G	Snap to grid

Select and edit

Ctrl + A	Select all
Ctrl + F	Find and replace
Ctrl + Shift + F	Find similar objects
Shift + X	Cross selection
Tab	Switch selection range
Ctrl + X	Cut
Ctrl + C	Copy
Ctrl + V	Paste
Delete	Delete selected
M	Move by center point
← → ↑ ↓	Nudge the selection
Space	Rotate left
Ctrl + D	Repeat to cursor
Ctrl + Shift + D	Repeat to other layers
Ctrl + G	Group
Shift + G	Ungroup
Ctrl + Z	Undo
Ctrl + Y	Redo

Schematic and symbol

Shift + F	Place device dialog
W	Wire
B	Bus
N	Net label
T	Text
P	Pin (symbol editor)
R	Rectangle
Alt + A	Arc
Alt + C	Circle
Alt + L	Polyline
Tab	Properties while placing

PCB routing

W	Route a single track[1]
Shift + W	Cycle track widths
L	Routing corner style
Space	Flip the path direction
Backspace	Back one segment
Enter	Finish
Esc	Cancel
V	Place a via
Shift + V	Cycle via sizes
Alt + D	Differential pair routing
Shift + A	Equal-length routing
Num +	Widen the tuning gap
Num –	Narrow the tuning gap

PCB layers and view

T	Top layer
B	Bottom layer
1 – 4	Inner layers 1 to 4
Num *	Next copper layer
Shift + Num *	Previous copper layer
Ctrl + L	Show all layers
Shift + S	Toggle layer brightness
F	Flip the board view
Ctrl + R	Toggle selected flylines
Ctrl + Q	Toggle net names

PCB parts, tools and copper

P	Place a single pad
X	Flip left to right
Y	Flip upside down
G	Select overlapping items
Alt + M	Measure distance
C	Command
Alt + S	Snap
Shift + B	Rebuild all pours
Shift + M	Hide or show pours

[1] Some setups route with Alt + W instead of W. [2] Zoom keys may be unassigned by default; the scroll wheel always works. Any key can be changed in Settings › Shortcut Keys, so a shared computer may differ.

EasyEDA Pro: designing a PCB		Rev A
Title: Complete shortcut list	Source: EasyEDA Pro docs	Sheet: 2 of 2