





Notes;
gpio0 to 8 have pullup resistors connected at boot. So, use gpio 27 [13] and gpio 22 [15].

Usage -
gpio 2 [3] - unused
gpio 3 [5] - Heater (n.c)
gpio 4 [7] - Temp Sensorer Data
gpio 17 [11] - Pump C.T. Via some electronics
gpio 27 [13] - Water Ctrl, One
gpio 22 [15] - Water Ctrl, Two
gpio 10, 9, 11 - unused

Revised Logger Adaptor Board (for Pi Zero)

7th December, 2024

David Bannon