





Notes;
 gpio0 to 8 have pullup resistors connected at boot. So, use gpio 27 [13] and gpio 22 [15].

Usage -
 gpio 2 [3] - unused
 gpio 3 [5] - Heater (n.c)
 gpio 4 [7] - Temp Sensorer Data
 gpio 17 [11] - Pump C.T. Via some electronics
 gpio 27 [13] - Water Ctrl, One
 gpio 22 [15] - Water Ctrl, Two
 gpio 10, 9, 11 - unused

Revised Logger Adaptor
 Board (for Pi Zero)
 28th November, 2024
 David Bannon