

Timer Socket Instruction Manual

Please read the instruction carefully before using.

Features:

Patented design

Optimal designed cooper structure ensures a longer service life

Minimum time setting is 1 minute.

8 programmable events times each day.

INSTRUCTION MANUAL

With LCD and integrated circuit, the words and numbers will be displayed clearly and accurately. It provides 8 groups ON/OFF switch each day. There are also many combinations between ON, ON AUTO, OFF and AUTO OFF.

Time Setting

Before using the timer, please reset the present time.

Press "CLOCK" and "HOUR" at the same time for setting the hour.

Press "CLOCK" and "MIN" at the same time for setting the minute.

Press "CLOCK" and "WEEK" at the same time for setting the week.

Timer Setting

Press "PROG" to enter into the setting mode, the screen displays "1 on"

Press "HOUR", "MIN", "WEEK" to set the date and time.

Press "PROG" again for the OFF time, the screen displays "1 off"

Repeat those three steps to set the following timer if needed. There are

totally eight groups of timer setting.

Weekly Setting

During Timer Setting, press "WEEK" once the screen will show MO, TU, WE, TH, FR, SA, SU, meaning entering daily on/off setting.

Press "WEEK" again, the week day will display in turn after each press. In this setting, the timer will only work in one week day.

After the screen showing "Su", it will show MO, TU, WE, TH, FR, the timer will work during weekdays. Press "WEEK" again, the screen will show SA, SU, the time will work at the weekends.

Press "WEEK" again, the screen will show the whole week except Sunday. That means the timer will work on the week day except Sunday.

Press "WEEK" again, the screen will show MO, WE, FR, the timer will work in these 3 days.

Press "WEEK" again, the screen will show TU, TH, SA, the timer will work in these 3 days.

Press "WEEK" again, the screen will show MO, TU, WE, the timer will work in these 3 days.

Press "WEEK" again, the screen will show TH, FR, SA, the timer will work in these 3 days.

Press "WEEK" again, there is no week day showing. The timer won't work in all days.

Timer ON/OFF/AUTO mode

Press , you could choose timer working mode

ON: the timer will keep working

AUTO: the timer will turn on and turn off according to the setting time

OFF: the timer is turned off.

Special Function

Press "WEEK" and "HOUR" at the same time, the screen will show "RND" at the right side. It means the turn-on time and the turn-off time will be extended from 2 minutes to 32 minutes randomly. Press "R" to reset time and timer.

NOTES

Output loading should not exceed. Please plug the timer into power mains to charging the built-in battery.

Timing error is 2minutes per month.

Summer time can be added to the timer.

This timer is 24-hour clock display. If there is no display on the LCD, please recharge the timer before using.

Example one

Please reference the instruction to set up the time and week

Target: turn off at 8:30am, turn on at 8:00 pm

Press 'PROG' button to enter into the setting mode. When the display shows "1ON"(which means that

this is the first group of timer setting, and we are just setting the time of switching on), press "HOUR" button to set the time to 20:00. Press "PROG" button again, when the display shows "1 OFF", press "HOUR" and "MIN" button to set the time to 8:30. Press "CLOCK" button to go back. Press  button to set the timer to ON AUTO mode. Then the all setting process is finished.

Example two:

Target: turn on at 8:30 am, and turn off at 8 pm

Press 'PROG' button to enter into the setting mode. When the display shows "1 ON" (which means that this is the first group of timer setting, and we are just setting the time of switching on), press "HOUR" and "MIN" button to set the time to 8:30. Press "PROG" button again, when the display shows "1 off", press "HOUR" button to set the time to 20:00. Press "CLOCK" button to go back. Press  button to set the timer to AUTO OFF mode. Then the all setting process is finished.