



BRmesh

USER MANUAL

1. Download "BRmesh"



Select  or  to download "BRmesh" to your mobile phone.

2. Or Scan the QR Code to download the App.



3. Open Bluetooth and the APP, then follow the instructions to add the lamp to BRmesh.

No network,
No registration.



*Product supported mobile phone system:
Android 6.0 or higher system, IOS 12.0 or higher system.

BRmesh-S

USER MANUAL

Thank you for purchasing our products. Please read the following information carefully in order to fully use the product.



PRODUCT FEATURES

- This is a Bluetooth connection, APP controlled LED light, no network, no registration.
- Suitable for daily lighting, atmosphere lighting and decorative lighting.



FEATURES OF RF

- RF signals can cross cloth, glass, etc. Walls, metal, etc. will severely shorten the distance of signal transmission.
- The connection distance between the mobile phone and the lamp depends on the Bluetooth chip of the mobile phone, that is, different mobile phones have different connection distances.



PRECAUTIONS

- Please be sure to cut off the power before inserting or removing the lamp from holder.
- Not compatible with dimmers, the device will appear flashing, timing inaccuracy, shifting mode instability, etc.
- DO NOT USE UNDER THE WATER!



LOCATION INFORMATION

- To enable Bluetooth scanning on your phone, the Android system requires access to the location information to be turned on in order to perform the Bluetooth scanning function.
- The Android APP requires Bluetooth scanning to perform the following three tasks only:
 1. Add device
 2. Grouping modification on the Main Phone
 3. View and set timing
- If you do not need to use the above functions, disabling the location information will not affect the use of others.
- IOS system does not require the access to the location information.



THE PHONE MUST IN CLOSE PROXIMITY TO THE LIGHTS FOR THE FOLLOWING TASKS

1. Add device

The distance between the phone and the lights is recommended to be within 25ft and without any large obstacles in between.

2. Grouping modification on the Main Phone

The distance between the phone and the lights is recommended to be within 40ft and without any large obstacles in between.

3. Set timing

The distance between the phone and the lights is recommended to be within 40ft and without any large obstacles in between.

- The effective distance may vary depending on the phone.

+ ADD DEVICE

- When downloading the APP, please be sure that the icon and the APP name are consistent with the instructions.
- You need to add the light to the app when use it at the first time.
- Open the APP ↓



Note:

Tick the "I have understood" box and click on the "Enter to add" button on the Add guidelines page to proceed to the Add device page, then turn the light(s) off and back on to discover the device(s).

⌚ TIMING

- Timing function is available only when controlling one lamp, there is no timing function when controlling multiple lamp.
- Sub-phones are not supported.
- Cancel timing.
 1. Cut off the power.
 2. Please go to the setting of APP

📱 SHARING AND SCANNING DEVICES

- Main phone:
The mobile phone which can add device through the "Add device" page.
- Sub-phones:
The mobile phone which can add the device shared by the main phone through the "scanning function".

FUNCTION TABLE

	Main Phone	Sub Phone
Share device	✓	✗
Add device	✓	✗
Color	✓	✓
Mode	✓	✓
Manage group and device	✓	✓
Scene	✓	✗
Timing	✓	✗
Scanning function	✗	✓

Scan only the original main phone

Remarks: If you need to recover the "add device" function on the sub phone, please delete all the devices of the sub phone.



SOLUTIONS FOR ABNORMAL DURING CONTROL


1. Exit the APP.
2. Turn off the the Bluetooth of phone.
3. Turn on Bluetooth after 1 minute.
4. Start the app.



ABOUT MESH

- Connect one of the lamp through the Bluetooth of mobile phone (app automatically recognizes) to control all lights.
- Different brands or models of mobile phones may have different distances.

Schematic diagram ▼



Tips:

- Walls, metals, etc. will severely shorten the distance of signal transmission.
- It is recommended that the distance between the lamp and the lamp is less than 25ft (no obstruction in the middle), subject to actual use.
- If a lamp is completely out of control, it may be that the distance between the lamp and the nearest lamp is greater than 25FT.
- There is no need to connect to the network when using this APP, so the status cannot be displayed completely accurately and in time.



If you find any problems that can't not be solved or any suggestion to improve the products when using, please feel free to contact us, our after-sales team will offer you a 100% perfect service at any time.