


Instructions Manual

Read these instructions before using the heater.
Keep for reference in the future.



At the bottom you will see a coiled metal rod. You may think that this is the zone where most of the heating takes place. But that is wrong. Right from top to bottom it heats up at the max. This device must be immersed completely up just before the black box begins. Notice the label "level of immersion" This device must be immersed up to that point.

The entire metal rod that you see in view should be immersed. You may leave up to 1 cm gap before the black box. Do not immerse the Black box. That will cause a short circuit and may cause burns. Most of the immersion heaters are provided with a hook at the top. You will notice a small metal jutting out of the black box above between the two rods.

That hook is used to attach to the side of the bucket. Make sure the bucket is filled with water. The water level should naturally stop at the level indicated after you have comfortably hooked the heater with the bucket. Now plug in the heater. Never remove the heater from the bucket while it is still on. As long as it is under water it is safe. It won't melt the plastic as that requires large temperature. The heater will never rise above 100 deg Celsius as the water won't allow it. Depending on the power rating and the capacity of the Bucket, this may take anywhere from 8 minutes to 18 minutes to heat the water up to 100 deg. Leave it for longer duration and you may even cause it to reach boiling point.

Once it is heated up enough. Unplug the heater. Wait for 1 minute, then remove the heater and place it in dry place.

Precautions. Never turn on the heater in an open dry place. It must be started under water only.

Do not dip the black box inside the water.

Don't touch the water once the heater is on. In case of bad earthing you may get a shock. If earthing is good then it is safe to touch the water.

Attention:

- The immersion heater can only used to heat water. It can not be used to heating oil or other liquids.
- Do not use in metal containers and bathrooms.
- Caution: Do not touch the hot water while the immersion heater is working.

Never leave the immersion heater unattended while using.

Unplugged before:

- Leave the room for a short time.
- In case of breakage.
- Remove from the water.
- Children are not aware of the dangers that may occur while handling the appliances. So never leave children use appliances.
- Under no circumstances put in Operating immersion heater if the device or cable show visible damage. The cable can not be replaced and if damaged, the heater has to be discarded.
- Before using the appliance for first recommend that you sterilize the heater clean water 5 times without using that water.