

2021 TAMU Purchase
Amazon CDMALL Store (\$17.99 in 2026)

Fan Speed Controller

User Manual

120v 15 A max



Please read this manual thoroughly before the operation and keep it for future reference.

⚠ Safety Instructions


1. Voltage applied on this appliance should match the rated power.
2. When operating the appliance, avoid body contact with grounded surfaces such as pipes and radiators.
3. The environment where this appliance is used should be kept clean, dry and well lighted
4. Children are not allowed to operate this appliance for safety concerns.
5. When this appliance is not in use, disconnect its power and store it in a dry place. Keep it out of the reach of children.
6. When operating this appliance, the operator should wear protective and electrically nonconductive clothes and footwear. Do not wear loose clothing, jewelry and other accessories as it might be caught by the moving parts.
7. When operating this appliance, wear safety goggles.
8. Maintain and check the appliance in regular intervals. If there is damage on its parts or cords, stop using it immediately.
9. Do not modify the appliance by yourself and do not use it for other purposes that it is not intended for.
10. Use caution when you are operating the appliance. Do not operate the appliance after drinking alcohol or taking medicine.
11. If an extension cord is required, it must be of proper size and type to be compatible with the appliance. This appliance requires extension cord of **15 amps (up to 50 feet)** and wire size rated at **18 AWG**.
12. The regular maintenance on this appliance should be carried out by a qualified technician.

Specifications

Rated Power	110 V
Rated Current	15 A
Power	1800 W

Operation Instructions


1. Connect the fan speed controller to your fan. After that connect the power cord of the fan speed controller to a power outlet.
2. For variable speeds, turn the power switch to "VAR" side and then rotate the speed adjusting knob to set the spinning speed of your fan.
3. For full speed, turn the power switch to the "FULL" side and the fan will spin at the full speed. In this mode, the speed adjusting knob could not adjust the speed anymore.



Changing Fuse

Size(in)

Change the fuse by referring to the right picture.



Component Diagram

Notes: The diagram is for reference only. The product might differ.

Item #	Description	Qty
1	Fuse Lid	1
2	Fuse	1
3	Fuse Holder	1
4	Washer	1
5	Wire	1
6	Nut	1
7	Face Plate	1
8	Rocker Switch	1
9	Screws	4
10	Speed Knob	1
11	Nut	1
12	Washer	1
13	Potentiometer	1
14	Circuit Board	1
15	Housing	1

Item #	Description	Qty
16	Rectifier	1
17	Hold Clamp	1
18	Plug	1
19	Outlet Socket	1
20	Cord	1
21	Cord Clamp	1
22	Screws	2

