

Details for Order #114-2384763-9411437

[Print this page for your records.](#)

Order Placed: February 11, 2025
Amazon.com order number: 114-2384763-9411437
Order Total: \$99.59

Not Yet Shipped

Items Ordered	Price
1 of: <i>Hollyland Lark M2 Wireless Lavalier Microphone for iPhone15/16&Android, USB C Mini Lapel Microphone Wireless, 1000ft Range, Hi-Fi Audio, Noise Cancellation, 30H Battery for Video Recording, Streaming</i>	\$92.00
Sold by: Hollyland Official Store (seller profile)	
Supplied by: Other	
Condition: New	

Shipping Address:

Shipping Speed:
FREE Prime Delivery

Payment information

Payment Method:	Item(s) Subtotal:	\$92.00
	Shipping & Handling:	\$0.00

	Total before tax:	\$92.00
	Estimated tax to be collected:	\$7.59

	Grand Total:	\$99.59

To view the status of your order, return to [Order Summary](#).

[Conditions of Use](#) | [Privacy Notice](#) © 1996-2025, Amazon.com, Inc. or its affiliates

Back to top



English

United States

Help




LARK M2

User Manual

V1.0


Version Overview

LARK M2 Duo (Lightning)




LARK M2 Duo (USB-C)

◀ my version




Version Overview

LARK M2 Duo (Camera)



Version Overview


LARK M2 Combo




* The quantity of the items depends on the product configuration.

Product Overview

Mobile Version




Camera Version




Product Overview

TX: Transmitter




Mobile Version RX: Receiver (Lightning/USB-C)




Product Overview

Camera Version RX: Receiver




Product Usage (Mobile Version)

- ① The preferred placement for TX is at the collar. If speaking with a loud volume, you can choose an upper chest position. You can wear it using either the back clip or clip magnet.




- a. Place the clip magnet on the back of the collar, and secure TX on the front of the collar with the magnet.



- b. Clip the back clip onto the collar, and secure TX with the clip.

- ② A magnet necklace for the clip magnet is included, allowing you to secure TX around your neck.



- * In order to achieve the best possible sound quality during recording, it's important to place the TX correctly. Make sure that the microphone is not covered by any cloth. If you are recording outdoors, it's recommended to use a windscreen to minimize unwanted noise caused by the wind and breathing sounds.

Product Usage (Mobile Version)


- ① Plug RX (Lightning) into phone



- ② Plug RX (USB-C) into phone





- ③ Charge your phone through the RX for simultaneous charging and usage



Product Usage (Camera Version)

Connect RX to camera

1. Attach the RX to the camera's hot shoe/cold shoe using the back clip;
2. Connect the RX's 3.5mm audio output port to the camera's 3.5mm audio input port using a 3.5mm TRS to TRS cable;
3. Set the camera's recording volume to the minimum level and the receiver's output volume to the medium level to ensure best recording quality.



Indicator Description

TX Indicator Lights

Description	Status
Blue light flashing	TX and RX not connected
Blue light steady	TX and RX connected
Green light steady (in use)	Noise Cancellation ON
Pink light steady	TX updating
Orange light steady	TX charging
Green light steady (while charging)	TX fully charged
Red light flashing slowly	TX low battery

Mobile Version RX Indicator Lights

Description	Status
Blue light flashing	TX and RX not connected
Blue light steady	TX and RX connected
Green light steady (in use)	Noise Cancellation ON
Pink light steady	RX updating
Red light flashing slowly	TX low battery

Camera Version RX Indicator Lights

Description	Status
Blue status indicator light flashing	TX and RX not connected
Blue status indicator light steady	TX and RX connected

Indicator Description

Green status indicator light steady (in use)	Noise Cancellation ON
Pink status indicator light steady	RX updating
Orange status indicator light steady	RX charging
Green status indicator light steady (while charging)	RX fully charged
Red status indicator light flashing slowly	TX low battery
Two red status indicator lights flashing quickly	RX low battery
Blue volume/mode indicator light steady	Stereo
Green volume/mode indicator light steady	Mono
One volume/mode indicator light steady	Low volume
Two volume/mode indicator lights steady	Medium volume
Three volume/mode indicator lights steady	High volume

Charging Case Indicator Lights


One LED ON	25% battery
Two LEDs ON	50% battery
Three LEDs ON	75% battery
Four LEDs ON	100% battery
One LED ON, steady red	Low battery level and cannot charge the RX and TX
One flashing LED when connected via USB	Charging
Four LEDs sequence on	Charging case updated

Automatic On/Off


Take the TX and RX out from the charging case to turn on automatically.
Place the TX and RX back in the charging case to turn off automatically.

Manual On/Off

Press and hold the TX power button for 3 seconds to turn on/off.




Press and hold the TX power button for 3 seconds




Press and hold the RX power button for 3 seconds

Noise Cancellation

1. Press the noise-cancellation button on TX to turn the function on or off. When noise cancellation is on, the status indicator on TX turns green.




2. Press the noise-cancellation button on the mobile version RX to turn the function on or off. When noise cancellation is on, the status indicator on the RX turns green.



Manual Pairing


1. With the TX off, press and hold the TX pairing button for 6 seconds to start pairing. The TX status light will quickly flash blue when in pairing.



2. For mobile version RX, connect it to a phone and hold the pairing button for 3 seconds to start pairing. The RX status light will quickly flash blue when in pairing.



3. With the camera version RX on, hold the pairing button for 3 seconds to start pairing.




* The TX and the RX are pre-paired at the factory.

Automatic Charging


When the status indicator on TX turns into slow flashing red, or when both status indicators on RX turn into fast flashing red, place them in the charging case and they will start charging automatically. Solid orange indicates charging in progress. Solid Green indicates charging completed.

Manual Charging

When the status indicator on TX turns into slow flashing red, you can charge the TX using the magnetic charger. Solid orange indicates charging in progress. Solid Green indicates charging completed and the light will go off 30 minutes later.




When both status indicators on the camera version RX turn into fast flashing red, you can charge the RX using the charging cable. Solid orange indicates charging in progress. Solid Green indicates charging completed and the light will go off 30 minutes later.



Video Recording Control

While shooting with your phone, double-press the button on TX to start or stop video recording.




* This function only works when the camera app of your phone supports the function of controlling video recording by pressing the volume key.

Mode Switching (Camera Version RX Only)

Connected to a phone: The green light stays on. Only support mono mode.

Connected to a camera: The blue light stays on, indicating stereo mode; the green light stays on, indicating mono mode.

To switch mode, simply press the mode switching button on the RX.



Volume Lock (Camera Version RX Only)

To lock the current volume level on the Camera Version RX, simply double-click the power button.

If you need to adjust the volume again, double-click the power button once more to release the volume lock.



Volume Adjustment (Camera Version RX Only)

The factory default volume is set at medium level, with three levels available: high, medium, and low.



Turn the volume knob clockwise to turn the volume up.



Turn the volume knob counterclockwise to turn the volume down.

Note:

1. The mobile version only supports mono mode.
2. Only pair one RX to the TX during recording to ensure proper operation of the LARK M2 combo version.

Firmware Update

Mobile Version: Update via the Lark Sound app.

Camera Version: Update via the Lark Sound app or from Hollyland official website.

Lark Sound

The Lark Sound app is available for download on Xiaomi, Huawei, and Apple App Stores. You can also scan the QR code below to download the app.



Lark Sound

The Lark Sound app is a perfect match for Hollyland wireless microphones. With the app, you'll have access to a range of smart features, such as parameter configurations and firmware updates, that work together seamlessly to enhance your microphone performance.



Requires iOS 12.0 or higher



Requires Android 8.0 or higher



Specifications

Mic Sensitivity	-37 dBV ± 2dB @ 1 KHz, 94dB SPL
Wireless Modulation Mode	GFSK 2 Mbps
Wireless Transmission	2.4 GHz Adaptive Frequency Hopping (AFH)
Transmission Range	Mobile Version: Up to 1000ft (300m) for LOS/200ft (60m) for NLOS
	Camera Version: Up to 1000ft (300m) for LOS/130ft (40m) for NLOS
Mic Polar Pattern	Omnidirectional
Frequency Response	20 Hz–20 kHz
Signal-to-Noise Ratio	> 70dB
Sound Pressure Level	115dB SPL
Bit Depth	24-bit
Sample Rate	48kHz
Battery Voltage	TX: 3.87V Camera Version RX: 3.87V Mobile Version Charging Case: 3.8V Camera Version Charging Case: 3.8V
Battery Capacity	TX: 97 mAh Camera Version RX: 145 mAh Mobile Version Charging Case: 750 mAh Camera Version Charging Case: 1950 mAh

Specifications

Operating Time	TX: About 10 hours Camera Version RX: About 9 hours Mobile Version Charging Case: > 2 times charging for 2 TX at the same time Camera Version Charging Case: > 3 times charging for all TX and RX at the same time
Charging Time	TX: About 1.5 hours Camera Version RX: About 1.5 hours Mobile Version Charging Case: < 1.5 hours Camera Version Charging Case: < 2 hours
Charging Temperature	0° C to 45° C
Operating Temperature	-10° C to 45° C
Dimensions	TX: Approx. D26mm x 9.9mm (1.0" x 0.4") Mobile Version RX: Approx. 40mm x 16.5mm x 9mm (1.6" x 0.6" x 0.4") Camera Version RX: Approx. 40mm x 25.7mm x 20.5mm (1.6" x 1.0" x 0.8") Mobile Version Charging Case: Approx. 75.8mm x 49.8mm x 35mm (3.0" x 2.0" x 1.4") Camera Version Charging Case: Approx. 86mm x 54mm x 39mm (3.4" x 2.1" x 1.5")
Weight	TX: Approx. 9g (0.3oz) Mobile Version RX: Approx. 6g (0.2oz) Camera Version RX: Approx. 14.8g (0.5oz) Mobile Version Charging Case: Approx. 65.6g (2.3oz) Camera Version Charging Case: Approx. 111g (3.9oz)

*The data provided above is based on laboratory testing results.

If you encounter any problems in using the product or need any help, please contact Hollyland Support Team via the following ways:



Hollyland User Group



HollylandTech



HollylandTech



HollylandTech



support@hollyland.com



www.hollyland.com

Statement:

All copyrights belong to Shenzhen Hollyland Technology Co., Ltd. Without the written approval of Shenzhen Hollyland Technology Co., Ltd., no organization or individual may copy or reproduce part or all of any written or illustrative content and disseminate it in any form.

Trademark Statement:

All the trademarks are owned by Shenzhen Hollyland Technology Co., Ltd.

Note:

Due to product version upgrades or other reasons, this User Manual will be updated from time to time. Unless otherwise agreed, this document is provided as a guide for use only. All representations, information, and recommendations in this document do not constitute warranties of any kind, express or implied.