Lecture 16 - Using UARTS

Tuesday, March 31, 2020 10:44 AM

Objectives: - Learn how UARTs communicate asynchronously - Learn how UARTs are configured

Key Communication Link Characteristics:

- Synchronous vs. Asynchronous
- Full-Duplex vs. Half-Duplex

Rs-232

DTE - Data Terminal Equipment - Like a terminal (terminal Emulator)
DCE - Data-Circuit Terminating Equipment - like a modem -(MX7)

Parity

Odd: 11001101 P:0 Total number of 1s including P is odd

Even: 11001101 P: 1