

Setup Guide

for XXXX Add-On

Version 8

Contents

1. System Requirements	1
2. XXXX Add-On Setup	2
2.1 Launch XXXX Add-On and Grant Access	2
2.2 Connect to the Central Server	2
2.3 Log in to the Central Server	3
2.4 Enter Device Name and Location	3
2.5 Choose Hardware Acceleration & Camera	3
2.6 Setup Complete	4
2.7 Error Handling	4
3. XXXX Add-On Settings	6
4. Using XXXX Add-On	15
4.1. Offline Use	15

1. System Requirements

Below are the system requirements for XXXX Add-On.

Device Requirements	
CPU	• Snapdragon 600 series • MediaTek Genio 350 • NXP i.MX8M Plus
Memory	• 2 GB
OS	• Android 11 or above
Storage (Free space)	• 4 GB

2. XXXX Add-On Setup

Follow these steps to set up XXXX Add-On on your device.

- [2.1 Launch XXXX Add-On and Grant Access](#)
- [2.2 Connect to the Server](#)
- [2.3 Log in to the Server](#)
- [2.4 Enter Device Name and Location](#)
- [2.5 Choose Hardware Acceleration](#)

2.1 Launch XXXX Add-On and Grant Access

1. XXXX Add-On requires access to your videos and files. Select the **WHILE USING THE APP** option to allow the facial recognition software to take photos and record video with the device's camera.
2. Tap the **Start** button to launch the XXXX Add-On app.

2.2 Connect to the Central Server

XXXX Add-On needs to connect to the facial recognition software's server to register the device to the server. XXXX Add-On will auto search for available servers and provide IP addresses for you to select.

1. Select the server URL from the list or you can manually enter it in the field provided.
2. Tap **Continue**. XXXX Add-On will connect to the server, where you can now register the device.

2.3 Log in to the Central Server

After connecting to the server, enter your **Account** and **Password** to sign in the facial recognition software's server, and then tap **Login** to register the device to the server.

2.4 Enter Device Name and Location

After logging into the server, fill in the **Device Name** and then select an existing **Location** from the drop down to register the device to the server. You can also choose to enter a new location, if required.

Tap **Continue** so you can recognize and monitor the device through the Security Console for the server.

2.5 Choose Hardware Acceleration & Camera

Choose the correct hardware acceleration and camera to complete the setup flow.

Note: different devices have different hardware acceleration methods. Please confirm the device chip and the hardware acceleration it supports.

1. Select the **Acceleration** method from the drop down. The following acceleration methods are supported.
2. Choose a **Camera** to apply the different camera settings and the Anti-Spoofing.

2.6 Setup Complete


The setup of XXXX Add-On is not complete. Once the initialization is complete, you can start using the XXXX Add-On service.

See [Using XXXX Add-On](#) for more information.

2.7 Error Handling


The following are potential errors you may encounter and how to fix them.

- Trying to connect to a non-existent server or cannot connect to the network.



For this case, check that the URL you entered is correct, including whether it is using HTTP or HTTPS, and that the device you are using is connected to the correct network.

- Incorrect account or password information entered when logging in to the facial recognition software.



For this case, check that you entered the account and password correctly, and then try again.

3. XXXX Add-On Settings

Before using XXXX Add-On, you should configure the settings to ensure it works to your specifications.

To configure the settings, do this:

1. In the XXXX Add-On program, tap the  button.
2. Enter your **Account** and **Password** information in the fields provided.
3. In the Settings window, you can configure the below settings. When you are done, tap  to return to the main XXXX Add-On window.

People Database

In this section you can add new people into the People Database by adding their personal information and scanning their face with the Face Terminal device.

Add Person

To add a new person to the People Database, do this:

1. Tap **Add Person**.
2. In the fields provided, enter the following required information:
 - **Name:** enter the name of the person you want to add.
 - **Group:** select which people group the person belongs to.

3. In the fields provided, enter the following option information, or you can do it later in the facial recognition software.
 - **E-mail:** if required, enter the person's e-mail address.
 - **Employee ID:** if required, enter the person's employee ID.
 - **Sub-Group:** if required, add the sub-groups the users should be added to.
 - **Company/Department:** if required, enter the company or department for the person.
 - **Business Title:** if required, enter the business title for the person.
 - **Notes:** if required, enter any useful notes about the person.
4. When done entering the information, tap **Next**.
5. Ask the person who you are adding to the People Database to stand in front of the face terminal device, and then tap **Start Camera**.
6. Following the instructions on the device to capture the photo.
7. When done, tap **Retake Photo** if you want to capture another photo. Tap **Confirm & Enroll** to complete the process and add the person into the People Database.

Access Control Options

If Access Period is enabled for the people group selected for the new person, you can set the following access control options:

- **Access Period Start Date:** select the date you want the visitor access period to begin.
- **Access Period End Date:** if you want to set an end date, select the **Specified Date & Time** option and then select the date you want the visitor's access period to end. You can also select **No End Date** so access does not expire.

About this Face Terminal

In this section, you can configure all of the general XXXX Add-On settings.

Server

Tap on this option to change which server XXXX Add-On is connected to. To change, tap the **Change Server** button, and then **Continue** to disconnect from the current server. See [Connect to the Server](#) for the full details on how to connect to a different server.

Device Name

Tap this option to change the name of the current device. Type in the new name in the field provided, and then tap **Save** to set the change.

Device Location

Tap to change the location information of this device. Select or enter a new device location in the field provided, and then tap **Save** to set the change.

Hardware

Tap on this option to change hardware acceleration SoC used for speeding up facial recognition and camera for anti-spoofing. See [Choose Hardware Acceleration & Camera](#) for more details. After updating the settings, tap **Save** to set the changes.

Version

In this section you can find the XXXX Add-On version number.

Facial Recognition

In this section, you can update the following facial recognition settings.

Recognition Size of Face

Tap this option to set the minimum face size that will be recognized by XXXX Add-On in the camera's video image. Use the slider to adjust the minimum face size, and then tap **Save** to set the change.

Recognition Precision

This option allows you to choose the precision of the facial recognition for allowed entry. You can set the balance between ease of use (high TAR) and accuracy (low FAR), i.e. set the trade-off between user convenience and recognition accuracy. Tap to select one of the recognition precision options, where $3e-7$ is very strict and $1e-4$ is more lenient, and then tap **Save** to set the change.

Anti-spoofing

Tap the **Anti-spoofing** option to enable anti-spoofing. When enabled, Face Terminal will protect against spoofing attempts that use printed photos, screens, or other devices to try and gain access. This option increases the face detection time.

Anti-spoofing Precision Mode

When Anti-spoofing is enabled, you can set the precision mode used to check for spoofing attacks. **High Precision** blocks more attacks, while **Fast** is quicker and easier for real users.

Note: this option is only available for 2D anti-spoofing.

Image Quality Check

Tap the **Image Quality Check** option if you want XXXX Add-On to check the quality of captured photos to ensure the accuracy of recognized faces. When enabled, the face detection time increases.

Visitor Recognition Records

Enable the **Visitor Recognition Records** option if you want to display visitor display cards when visitors are recognized by XXXX Add-On. When enabled, the visitor information will be kept and stored on the server.

Maximum Queued Records

Tap this option to set the amount of queued records that can be stored when XXXX Add-On is offline. Drag the slider to set the maximum number of queued records, and then tap **Save** to set the change.

Display Preferences

In this section, you can update the following display preferences.

Messages

Tap on **Messages** if you want to customize the messages that will display when VIPs, employees, people groups, and visitors are recognized by XXXX Add-On. You can enter custom messages for both when access is granted for each group, and when access is denied. Tap **Save** to set the changes.

Note: this feature is not available when in landscape view.

Display Card Duration

Tap on this option to set how long a VIP, employee, and visitor display card is displayed on the screen after they are recognized by XXXX Add-On. Select one of the available duration options, and then tap **Save** to set the change.

24-Hour Clock

Tap on the **24-Hour Clock** option to change the time format used to a 24-hour clock. Tap again to disable and use the 12-hour clock.

Languages

Tap this option to set the UI language for XXXX Add-On. Select the preferred language from the drop-down, and then tap **Save** to set the change.

Logo Image

You can change the logo that displays in the top left corner of XXXX Add-On screen.

Note: if you plan to use Face Terminal in the landscape view, the logo must be a 1x1 square image.

To change the logo, tap this option, and then tap the current logo. Select the image from your photo library, and then tap **Save** to set the change. For the best results, the image should not be larger than 894x140 pixels.

Hardware Dependent Options

If this section is available, you can configure the following hardware options.

Note: some of the following options are only available on certain devices.

2 Factor Authentication

Tap this option to enable 2 factor authentication for Face Terminal. Once enabled, both a person's card (employee ID badge) and face must match the person information that's in the database upon entry.

Wiegand Access Control

Tap the **Wiegand Access Control** option to enable door access through the Wiegand protocol. This feature is available for GIS YouMe-500, MSK Knoctoi Lite, and other compatible devices.

Wiegand Format

In the **Weigand Format** section, tap to select which card number bit length you want to set as the Weigand Format.

Signal Light

Tap the **Signal Light** option to enable the signal light on the device for a more intuitive visual indication of door access being granted or denied. This feature is available for GIS YouMe-500 and other compatible devices.

Daily Device Reboot

Tap to enable the **Daily Device Reboot** option if you want XXXX Add-On to automatically reboot the terminal device daily to free up memory and resources.

Daily Reboot Schedule

In the **Daily Reboot Schedule** section, after enabling the above option, set the time of day you want the device to reboot.

Advanced

In this section, you can update the following advanced settings.

Troubleshooter

Tap the **Start** button to use the Troubleshooter tool to help you diagnose any software or hardware issues you may be experiencing. After the Troubleshooter is done running some tests, the results will be displayed. Review the results and resolve any of the issues as required. Take screen

shots of the results and send them to the development team if you need any assistance.

Collect Logs

Tap the **Send** button within this option if you want to send all the application logs from this device to the server.

4. Using XXXX Add-On

After you have set up and configured the XXXX Add-On settings, the program is ready to use.

VIPs, employees, and visitors can place their face within the square detection area, so they can be recognized by XXXX Add-On.

4.1. Offline Use

XXXX Add-On will continue to function, even when offline. Facial recognition will continue, and all captured photos are saved on the device, which are later transferred when reconnected.

When your device is facing a connection issue, an icon will display in the top right corner of the capture window to inform you.

The following is a list of possible reasons for the connection issue:

- the device XXXX Add-On is installed on is not currently connected to the Internet. Check the network connection to ensure the device can connect normally.
- XXXX Add-On is experiencing connection issues because the network the device is connected to is unstable. Check that the network environment is working normally.
- the server is currently undergoing maintenance. The network connection should resume once the the maintenance is complete.