0.1 HOW THE DC MOTOR WORKS

0.1.1 Task: MAKE DC MORTOT RUN

- 1. Connect the DC motor to the battery and make it run.
- 2. You can try different combinations to connect the terminals of the motor like:
 - + and -
 - - and +
 - - and -
 - + and +.




Figure 1: DC motor connection.

0.1.2 Questions:

- 1. In which direction the motor's shaft spins in different situations?
- 2. In which direction the electric current flow?
- 3. Why does motor is not spinning when both connectors are connected to + terminal of the battery?

0.1.3 Summary

The rotation of the DC motor depends on the direction of electric current.

0.1.4 Issues

0.1.4.1 When I connect the DC motor to + and - terminals of the battery the motor's shaft does not spin. Check the voltage of the battery... battery may be discharged.

dr. David Rihtaršič

Check the connectors of the motor... may be bad.

dr. David Rihtaršič