Baudrate

110 - Very old teletypes, early modems 300 - Acoustic couplers (early modem tech)

1200 - Early dial-up connections

2400 - Legacy serial devices 4800 - GPS modules, legacy hardware

9600 - Most common default for microcontrollers, sensors 14400 - Early modem standard

19200 - Industrial devices, data loggers

38400 - Legacy Linux serial consoles

57600 - Wireless modules (e.g. XBee, HC-12)

115200 - Common for modern dev boards (Arduino, ESP32) 230400 - High-speed data transmission

460800 - Debug interfaces, fast UARTs 921600 - Advanced debugging, flashing tools

1000000 - Specialized hardware, USB-Serial bridges (e.g. FTDI, CP210x)

https://cybersword.tech O ph1sher

in www.linkedin.com/in/cybersword-tech @davidwowa