

Addressing Modes of 8086

Q. What is an Addressing Mode Explain the various addressing modes supported by the 8086 microprocessor with appropriate examples.

[DEF] Definition to Remember

An Addressing Mode is the method by which an instruction specifies the location of its operand (the data to be processed). Because data can be located in registers, embedded in instructions, or stored in memory, 8086 provides multiple addressing modes to access it efficiently.

1. Register and Immediate Modes (No Memory Access)

Mode	Description	Example
Immediate	Data is provided directly inside the i	`MOV AX, 1234H` (AX = 1234H)
Register	Data is in an internal CPU register. (	`MOV AX, BX` (AX = BX)

2. Memory Addressing Modes (Uses Data Segment - DS)

Mode	Description	Example
Direct	16-bit memory offset address is explic	`MOV AL, [2000H]`
Register Indirect	Offset address is held in a base (`BX`	`MOV AX, [BX]`
Based	Effective Address = Base Register (`BX	`MOV AL, [BX + 04H]`
Indexed	Effective Address = Index Register (`S	`MOV AX, [SI + 08H]`
Based-Indexed	Effective Address = Base Register + In	`MOV AL, [BX + SI + 02H]`

3. Usage of Memory Modes

- * Register Indirect: Good for passing pointers.

* Ba

[MUST-WRITE] Must-Write Points (for 10 marks)

1. Addressing Mode specifies the location of the operand.
2. Immediate: Operand is constant in the instruction (MOV AX, 1234H).
3. Register: Operand is in a register (MOV AX, BX) -- extremely fast.
4. Direct: Memory offset is explicitly given (MOV AL, [2000H]).
5. Register Indirect: Address is inside a register (MOV AX, [BX]).
6. Based/Indexed: Adds a displacement to a Base (BX/BP) or Index (SI/DI) register.
7. Based-Indexed: Base + Index + Displacement ([BX+SI+02H]) -- used for 2D arrays.

[RECALL] Quick Recall

Addressing Modes -> Immediate (value) -> Register (AX=BX) -> Direct ([addr]) -> Indirect ([BX]) -> Based ([BX+disp]) -> Indexed ([SI+disp]) -> Based-Indexed ([BX+SI+disp])