

Cameron McClellan

Conceal
for reset button

Hole for battery cable to come out and plug in

Holes left open for microbit ports

Low enough so
battery and

microbit

Just touch

(only 20mm)

Just high enough to
keep the battery

Microbit snaps onto
the top

Battery on
bottom

Battery
about
wide 25mm

Top of microbit open
for button use and display

Roughly 25mm
battery is about
52mm

Roughly 40mm to fit microbit
into place

Start

Check
Accelerometer
Velocity

Send info
to other
Microbit

Other microbit
receives and
displays
velocity info

End