

NS-TRS232-02
RS232 / TTL
Use Arduino Giga Only (5v)
82C288
82C284
80C286 on IPC0193SOCKET (DIP-68) (v2)
*Note: 286 is not standard PLCC68 pinout!
fritzing