

PART B: OPERATIONAL RECORDS MANUAL ARCHIVING

1. Check on the Technical Supervision position the RECORDING computer <REC> that is actually MASTER.


**Note:**

Refer to the *Specific Configuration Data Table* of the SMM document for the correct value of the parameter <REC> for the hostname of the Recording computer.


2. Insert a blank DVD in the DVD drive of this Recording server.
3. From a position belonging to the same partition as the recording computer, launch "ecm" tool and then click on the "**Recording tool**" button to start the recording Graphical User Interface
The REC Utilities window is displayed




4. The list of 'Available Nodes' is opening. Click then on the name of the 'MASTER' recording node.
5. The 'TOOLS' window is displayed.



6. Select the DVD on the "**Media Selected**" button
7. Click on "**Initialize media: DVD**"



8. Click on "**Make archive on DVD**" button to begin manual archiving




9. The following "**Information**" window is displayed :

Archiving in Progress


Use "show admin" to monitor progress

close

10. Select the "**show admin**" button :



11. The following window appears :



12. At the end of archiving, the 'copy status' will be on state "**archived**"

