

# GameView Scoreboard Instructions – Volleyball Game Setup and Operation

This guide will walk you through setting up and operating your GameView scoreboard for a volleyball match.

## 1. Connect the iPad to the Scoreboard

- Ensure your controller device (iPad) is connected to the **same wireless network** as the scoreboard.
- Open the GameView app.
  - Note: GameView app should have access to Local Network in the iPad App Settings
  - Auto Lock in the iPad settings should be set to "Never"
- Enter the IP address and passcode for your scoreboard (available on your <u>GameViewBoards.com</u> dashboard).

#### **Demo Mode:**

Use gameview.fly.dev (no passcode) and tap Connect.

## 2. Select the Sport and Navigate Screens

- Switch the sport mode to Volleyball.
- The app includes five main screens:
  - o Game
  - Logbook
  - Players
  - Media
  - Settings

# 3. Set Match Settings

- Go to the **Settings** tab.
- Tap **Update Scoreboard** to load new content:
  - Team names and mascots
  - Player photos
  - Sponsor ads
- Use additional tools:
  - Power On/Off toggle for connected displays
  - Horn volume adjustment

## 5. Setup Teams and Players

- Navigate to the **Players** tab.
- Select the Home Team & Away Team
  - Team logos and mascots will automatically appear on the scoreboard.
  - These teams are setup through your GameViewBoards.com Dashboard

## 6. Use Game Controls

Navigate to the Game tab.

#### **Available Controls:**

- +1 Point: Tap to score for the selected team
- **Timeout**: Call a timeout (clock must be stopped)
- Start/Stop: Toggle the game or timeout timer
- + 1 Set: Tap to add a win to a team

### **Displaying Players:**

Players that are setup through your GameViewBoards.com dashboard with player photos can be displayed during game by tapping an Event (Serving, Ace, etc...) and then selecting the player. You can return to the Team Mascot by tapping **Return** 

## 7. Timeouts and Breaks

- The clock must be **stopped** before a timeout or break can be called.
- During a timeouts and breaks, sponsor ads will display automatically.
- Tap the Timer Icon in the top right for adding an intermission
  - Select the time, and any optional warning horns.
    (A final horn will sound at the completion)
  - Tap Start to begin the intermission timer between games.
- To exit, tap **Orange Counter** and confirm.

#### **Horn Access:**

Press and hold the **buzzer button** (top corner) to activate the horn at any time.

## 8. Manage Possession, and Adjustments

- Tap the **Serve Indicator** to toggle possession between teams.
- Hold on the scoreboard area and make edits.
  - o Change team names or colors:
  - Adjust the Score
  - Change the Set #
  - Adjust Timeouts left
  - Adjust the Clock

## 9. Media

• Media tab: Play GameView & School's videos

**Note:** You can add videos to your GameView Scoreboard by inserting a USB Drive into the GameView computer. The USB Drive should have your video files (.mp4 format) in a folder called "media". Then select **Update Scoreboard** in Settings to copy them to your scoreboard.

# Wrap-Up

Your scoreboard is now fully set up to run a complete volleyball match with GameView.