SysLibCallback.lib库2

SysLibCallback. lib库

注意:此库文件的应用依赖于运行应用程序的目标系统。请参考文 SysLibs_Overview. pdf。请注意,在Windows CE 下运行 SysLibDir. lib 功能可能会出现不安全线程。

这个库提供功能函数 SysCallbackRegister 和 SysCallbackUnregister, 分别用来激活 callback 功能和 runtime 事件的定义。

两个功能函数都是布尔型的,当必需的 callback 功能被成功的注册或注消时,它们会分别返回 TRUE,且整个过程都是实时的。

这callback功能的原型必须如下所示:

FUNCTION Callback: DWORD

VAR_INPUT

dwEvent:DWORD; // 事件

dwFilter:DWORD; // 过滤

dwOwner:DWORD; // 来源

 END_VAR

注意对于 RISC 和 Motorola 68k 的目标系统: callback 功能的名字必须以 "callback"为开始。

当功能函数被用来注册或注消功能调用时,都将采用下面的参数接口描述:

输入变量	数据类型	描述
iP0UIndex		要用来注册/注消而调用 callback 功能的 POU 的指针,这个指针必须在以前通过帮助操作 INDEXOF(〈function name〉)命令已经获得。
Event	_	被 callback 功能呼叫的 runtime 事件,其详细说明在 RTS_EVENT 的列举中。

RTS_EVENT 列举定义如下:

```
TYPE RTS_EVENT :
```

EVENT_ALL,

(* 一般事件 *)

EVENT_START,

EVENT STOP,

EVENT BEFORE RESET,

EVENT_AFTER_RESET,

EVENT SHUTDOWN,

(* 实时运行产生的例外 *)

EVENT EXCPT CYCLETIME OVERFLOW,

EVENT EXCPT WATCHDOG,

EVENT_EXCPT_HARDWARE_WATCHDOG,

EVENT_EXCPT_FIELDBUS,

EVENT_EXCPT_IOUPDATE,

(* 循环时间溢出 *)

(* IEC-任务的软看门狗终止 *)

(* 硬件看门狗终止。全局软件错误。 *)

(* 发生 Fieldbus 错误 *)

(* I0-更新错误 *)

(* 系统产生的例外 *)

EVENT EXCPT ILLEGAL INSTRUCTION,

EVENT_EXCPT_ACCESS_VIOLATION,

EVENT_EXCPT_PRIV_INSTRUCTION,

EVENT_EXCPT_IN_PAGE_ERROR,

EVENT_EXCPT_STACK_OVERFLOW,

EVENT_EXCPT_MISALIGNMENT,

EVENT_EXCPT_ARRAYBOUNDS,

EVENT EXCPT DIVIDEBYZERO,

EVENT EXCPT OVERFLOW,

EVENT_EXCPT_NONCONTINUABLE,

EVENT EXCPT NO FPU AVAILABLE,

EVENT_EXCPT_FPU_ERROR,

EVENT_EXCPT_FPU_DENORMAL_OPERAND,

EVENT_EXCPT_FPU_DIVIDEBYZERO,

EVENT_EXCPT_FPU_INVALID_OPERATION,

EVENT_EXCPT_FPU_OVERFLOW,

EVENT_EXCPT_FPU_STACK_CHECK,

(* 不合语法的指令 *)

(* 禁止访问 *)

(* 特别说明 *)

(* 页面错误 *)

(* 桟溢出 *)

(* 数据类型未校准 *)

(* 数组超出范围 *)

(* 被零点分开 *)

(* 溢出 *)

(* 不可连续 *)

(* FPU: 没有 FPU 可用 *)

(* FPU: 未指明的错误 *)

(* FPU: 正规的操作数 *)

(* FPU: 被零点分开 *)

(* FPU: 无效的操作 *)

(* FPU: 溢出 *)

(* FPU: 检查栈 *)

(* IO 事件 *)

EVENT_AFTER_READING_INPUTS,

EVENT_BEFORE_WRITING_OUTPUTS,

```
(* 混杂事件 *)
 EVENT_TIMER,
                                          (* 标记时间表(计时器中断)*)
 EVENT_DEBUG_LOOP,
                                          (* 循环断点处的调试 *)
  (* 在线服务 *)
 EVENT_ONLINE_SERVICES_BEGIN := 500,
 EVENT_LOGIN,
 EVENT_CUSTOM_SERVICES,
  (* 中断 *)
 EVENT_INT_0:=1000,
 EVENT_INT_1,
 EVENT_INT_2,
 EVENT_INT_3,
 EVENT_INT_4,
 EVENT_INT_5,
 EVENT_INT_6,
 EVENT_INT_7,
 EVENT_INT_8,
 EVENT_INT_9,
 EVENT_INT_10,
 EVENT_INT_11,
 EVENT_INT_12,
 EVENT_INT_13,
 EVENT_INT_14,
 EVENT_INT_15,
 EVENT_INT_255:=1255,
 EVENT\_MAX
);
END_TYPE
```