## The Libray SysLibForce.lib

This library contains a function to start the forcing in the runtime system. The execution is synchronous.

Note: This library is used in connection with the 3S CANopen stack, to force variables before updating the output image (this means before sending the PDOs) and at reading the inputs. The call will be made automatically if the library is included in the project. The user must not call this function explicitly.

## **RtsPerformForce**

Starts forcing of variables in the runtime system.

Note: See above.

TRUE is returned after the operation has been finished successfully, otherwise FALSE.

Input- Variable	Data type	Description
_	_	_