EP.L3800 Elevator Control Panel

ACCESSORIES

**Biometrics Reader**

RFID Reader

HIO

HIO.EXP

- Support 8 floors by default (expendable to 136 Floors max.)
- Support timezone control bypass for individual floor
- Support up to 4 readers max.
- Support both RFID & biometrics readers
- Emergency bypass function by software
- Emergency bypass function by key Switch

Ordering Information

EP.L3800.PSU   Entrypass 4 Readers Advanced Serial Elevator Control Panel with Power Supply Unit

Basic System Diagram