

U100
FAULT#24RETE / V_L1

Timing diagram for U100 (FAULT#24RETE / V_L1) showing signals A1 through A18 and their corresponding pin numbers.

Signals and Pin Numbers:

- A1: 1
- A2: 2
- A3: 3
- A4: 4
- A5: 5
- A6: 6
- A7: 7
- A8: 8
- A9: 9
- A10: 10
- A11: 11
- A12: 12
- A13: 13
- A14: 14
- A15: 15
- A16: 16
- A17: 17
- A18: 18

Additional signals and pin numbers shown in the diagram:

- A1: 19
- A2: 20
- A3: 21
- A4: 22
- A5: 23
- A6: 24
- A7: 25
- A8: 26
- A9: 27
- A10: 28
- A11: 29
- A12: 30
- A13: 31
- A14: 32
- A15: 33
- A16: 34
- A17: 35
- A18: 36

NC pins are intentionally unused. SMD probe connects on the module top.

J1

MOTION 5V IN

1 +5V_MOTION

2 GND

C8 10u

GND

3V3

R8 10k

GND

J6

INTERNAL SERVICE KEY

1 USER_KEY_N

2 GND

#FLG2 Supply boundary

GND

#FLG3 Sample boundary

GND 3V3

H1 M2 clearance

H2 M2 clearance

H3 M2 clearance

Physical disable is J6: reset can cause a fail.

J6 is a user button. Physical disable is J8; reset can cause a fall.

[illegible]

3.3 V logic; actuator thresholds and timing remain bench items.

[illegible]

CLR_N dominates. Re-arm requires a new ARM_CLK edge; this is not a watchdog

[illegible]

CAN_3V3 powers translator B only. It does not power the motion MCU.

3.3 V logic; actuator thresholds and timing remain bench items

OE_N = request_N OR ARM_Q_N. Pull-ups disable TX by default.

SPI and DRDY belong to the rigid body IMU, not the head.

Inputs Scaling is on the power board.

1k / 10nF filters at the ADC inputs. Scaling is on the power board