sysfs-driver-hid-picolcd..txt

What: /sys/bus/usb/devices/<busnum>-<devnum>:<config num>. <interface

num>/<hid-bus>:<vendor-id>:<product-id>.<num>/operation mode

Date: March 2010

Contact: Bruno Prémont <br/>
bonbons@linux-vserver.org>

Description: Make it possible to switch the PicoLCD device between LCD

(firmware) and bootloader (flasher) operation modes.

Reading: returns list of available modes, the active mode being

enclosed in brackets ('[' and ']')

Writing: causes operation mode switch. Permitted values are

the non-active mode names listed when read.

Note: when switching mode the current PicoLCD HID device gets disconnected and reconnects after above delay (see attribute operation mode delay for its value).

What: /sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle . \langle interface

num>/<hid-bus>:<vendor-id>:cproduct-id>.<num>/operation\_mode\_delay

Date: April 2010

Contact: Bruno Prémont <bonbons@linux-vserver.org>

Description: Delay PicoLCD waits before restarting in new mode when

operation mode has changed.

Reading/Writing: It is expressed in ms and permitted range is

0..30000ms.

What: /sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle .\langle interface

num>/<hid-bus>:<vendor-id>:cproduct-id>.<num>/fb update rate

Date: March 2010

Contact: Bruno Prémont <br/>
bonbons@linux-vserver.org>
Description: Make it possible to adjust defio refresh rate.

Reading: returns list of available refresh rates (expressed in

Hz),

the active refresh rate being enclosed in brackets ('[' and ']')

Writing: accepts new refresh rate expressed in integer Hz

within permitted rates.

Note: As device can barely do 2 complete refreshes a second it only makes sense to adjust this value if only one or two tiles get changed and it's not appropriate to expect the

application

to flush it's tiny changes explicitely at higher than default

rate.