sysfs-driver-hid-prodikeys..txt

What: /sys/bus/hid/drivers/prodikeys/.../channel

Date: April 2010 KernelVersion: 2.6.34

Contact: Don Prince <dhprince.devel@yahoo.co.uk>

Description:

Allows control (via software) the midi channel to which

that the pc-midi keyboard will output.midi data.

Range: 0..15
Type: Read/write

What: /sys/bus/hid/drivers/prodikeys/.../sustain

Date: April 2010 KernelVersion: 2.6.34

Contact: Don Prince <a href="mailto:dhprince.devel@yahoo.co.uk">dhprince.devel@yahoo.co.uk</a>>

Allows control (via software) the sustain duration of a

note held by the pc-midi driver. O means sustain mode is disabled. Range: 0..5000 (milliseconds)

Type: Read/write

What: /sys/bus/hid/drivers/prodikeys/.../octave

Date: April 2010 KernelVersion: 2.6.34

Contact: Don Prince <dhprince.devel@yahoo.co.uk>

Description:

Controls the octave shift modifier in the pc-midi driver. The octave can be shifted via software up/down 2 octaves.

O means the no ocatve shift. Range: -2..2 (minus 2 to plus 2)

Type: Read/Write