sysfs-class-uwb\_rc-wusbhc..txt

What: /sys/class/uwb\_rc/uwbN/wusbhc/wusb\_chid

Date: July 2008 KernelVersion: 2.6.27

Contact: David Vrabel <david.vrabel@csr.com>

Description:

Write the CHID (16 space-separated hex octets) for this host

controller.

This starts the host controller, allowing it to accept

connection from

WUSB devices.

Set an all zero CHID to stop the host controller.

What: /sys/class/uwb\_rc/uwbN/wusbhc/wusb\_trust\_timeout

Date: July 2008 KernelVersion: 2.6.27

Contact: David Vrabel <david.vrabel@csr.com>

Description:

Devices that haven't sent a WUSB packet to the host within 'wusb\_trust\_timeout' ms are considered to have disconnected and are removed. The default value of

4000 ms is the value required by the WUSB

specification.

Since this relates to security (specifically, the lifetime of PTKs and GTKs) it should not be changed

from the default.

What: /sys/class/uwb\_rc/uwbN/wusbhc/wusb\_phy\_rate

Date: August 2009 KernelVersion: 2.6.32

Contact: David Vrabel <david.vrabel@csr.com>

Description:

The maximum PHY rate to use for all connected devices.

This is only of limited use for testing and development as the hardware's automatic rate adaptation is better then this simple control.

Refer to [ECMA-368] section 10.3.1.1 for the value to

use.