The SAS Layer is a management infrastructure which manages SAS LLDDs. It sits between SCSI Core and SAS LLDDs. The layout is as follows: while SCSI Core is concerned with SAM/SPC issues, and a SAS LLDD+sequencer is concerned with phy/00B/link management, the SAS layer is concerned with:

- * SAS Phy/Port/HA event management (LLDD generates, SAS Layer processes),
- * SAS Port management (creation/destruction),
- st SAS Domain discovery and revalidation,
- * SAS Domain device management,
- * SCSI Host registration/unregistration,
- * Device registration with SCSI Core (SAS) or libata (SATA), and
- * Expander management and exporting expander control to user space.

A SAS LLDD is a PCI device driver. It is concerned with phy/00B management, and vendor specific tasks and generates events to the SAS layer.

The SAS Layer does most SAS tasks as outlined in the SAS 1.1 spec.

The sas_ha_struct describes the SAS LLDD to the SAS layer. Most of it is used by the SAS Layer but a few fields need to be initialized by the LLDDs.

After initializing your hardware, from the probe() function you call sas_register_ha(). It will register your LLDD with the SCSI subsystem, creating a SCSI host and it will register your SAS driver with the sysfs SAS tree it creates. It will then return. Then you enable your phys to actually start 00B (at which point your driver will start calling the notify_* event callbacks).

Structure descriptions:

And then all the phys are an array of my_phy in your HA struct (shown below).

Then as you go along and initialize your phys you also initialize the sas_phy struct, along with your own phy structure.

In general, the phys are managed by the LLDD and the ports are managed by the SAS layer. So the phys are initialized and updated by the LLDD and the ports are initialized and updated by the SAS layer.

There is a scheme where the LLDD can RW certain fields, and the SAS layer can only read such ones, and vice versa. The idea is to avoid unnecessary locking.

enabled -- must be set (0/1) id -- must be set [0, MAX_PHYS) class, proto, type, role, oob_mode, linkrate -- must be set oob_mode -- you set this when 00B has finished and then notify the SAS Layer.

sas_addr -- this normally points to an array holding the sas address of the phy, possibly somewhere in your my_phy struct.

attached_sas_addr -- set this when you (LLDD) receive an IDENTIFY frame or a FIS frame, _before_ notifying the SAS layer. The idea is that sometimes the LLDD may want to fake or provide a different SAS address on that phy/port and this allows it to do this. At best you should copy the sas address from the IDENTIFY frame or maybe generate a SAS address for SATA directly attached devices. The Discover process may later change this.

frame_rcvd — this is where you copy the IDENTIFY/FIS frame when you get it; you lock, copy, set frame_rcvd_size and unlock the lock, and then call the event. It is a pointer since there's no way to know your hw frame size _exactly_, so you define the actual array in your phy struct and let this pointer point to it. You copy the frame from your DMAable memory to that area holding the lock.

sas_prim -- this is where primitives go when they're received. See sas.h. Grab the lock, set the primitive, release the lock, notify.

port — this points to the sas_port if the phy belongs to a port — the LLDD only reads this. It points to the sas_port this phy is part of. Set by the SAS Layer.

ha -- may be set; the SAS layer sets it anyway.

11dd_phy -- you should set this to point to your phy so you can find your way around faster when the SAS layer calls one of your callbacks and passes you a phy. If the sas_phy is embedded you can also use container_of -- whatever you prefer.

struct sas_port -----The LLDD doesn't set any fields of this struct -- it only reads them. They should be self explanatory.

第2页

phy_mask is 32 bit, this should be enough for now, as I haven't heard of a HA having more than 8 phys.

11dd_port -- I haven't found use for that -- maybe other LLDD who wish to have internal port representation can make use of this.

```
struct sas ha struct ----
It normally is statically declared in your own LLDD
structure describing your adapter:
struct my_sas_ha {
       blah;
       struct sas ha struct sas ha;
       struct my phy phys[MAX PHYS];
       struct sas port sas ports[MAX PHYS]; /* (1) */
       bleh:
};
(1) If your LLDD doesn't have its own port representation.
What needs to be initialized (sample function given below).
sas addr -- since the SAS layer doesn't want to mess with
         memory allocation, etc, this points to statically
         allocated array somewhere (say in your host adapter
         structure) and holds the SAS address of the host
         adapter as given by you or the manufacturer, etc.
sas port
sas phy — an array of pointers to structures. (see
        note above on sas addr).
        These must be set. See more notes below.
num_phys -- the number of phys present in the sas_phy array,
         and the number of ports present in the sas_port
         array. There can be a maximum num_phys ports (one per
         port) so we drop the num ports, and only use
         num phys.
The event interface:
        /* LLDD calls these to notify the class of an event. */
        void (*notify ha event) (struct sas ha struct *, enum ha event);
        void (*notify port event) (struct sas phy *, enum port event);
        void (*notify phy event) (struct sas phy *, enum phy event);
When sas_register_ha() returns, those are set and can be
```

The port notification:

the SAS layer.

/* The class calls these to notify the LLDD of an event. */
void (*lldd_port_formed)(struct sas_phy *);
void (*lldd_port_deformed)(struct sas_phy *);
第 3 页

called by the LLDD to notify the SAS layer of such events

If the LLDD wants notification when a port has been formed or deformed it sets those to a function satisfying the type. A SAS LLDD should also implement at least one of the Task Management Functions (TMFs) described in SAM: /* Task Management Functions. Must be called from process context. */ int (*lldd_abort_task) (struct sas_task *); int (*11dd abort task set) (struct domain device *, u8 *1un); int (*11dd_clear_aca) (struct domain_device *, u8 *lun); int (*11dd_clear_task_set) (struct domain_device *, u8 *lun); int (*11dd I T nexus reset) (struct domain device *); int (*11dd lu reset) (struct domain device *, u8 *1un); int (*11dd query task) (struct sas task *); For more information please read SAM from T10.org. Port and Adapter management: /* Port and Adapter management */ int (*lldd_clear_nexus_port) (struct sas_port *); int (*11dd clear nexus ha) (struct sas ha struct *); A SAS LLDD should implement at least one of those. Phy management: /* Phy management */ int (*11dd control phy) (struct sas phy *, enum phy func); 11dd ha -- set this to point to your HA struct. You can also use container of if you embedded it as shown above. A sample initialization and registration function can look like this (called last thing from probe()) *but* before you enable the phys to do 00B: static int register_sas_ha(struct my_sas_ha *my_ha) int i; *sas phys[MAX PHYS]; static struct sas phy static struct sas_port *sas_ports[MAX_PHYS]; my ha->sas ha.sas addr = &my ha->sas addr[0]; for (i = 0; i < MAX PHYS; i++){ sas_phys[i] = &my_ha->phys[i].sas_phy; sas ports[i] = &my ha->sas ports[i]; my_ha->sas_ha.sas_phy = sas_phys; my_ha->sas_ha.sas_port = sas_ports; my_ha->sas_ha.num_phys = MAX_PHYS;

my_ha->sas_ha.11dd_port_formed = my_port_formed;

第4页

```
my ha->sas ha.11dd dev found = my dev found;
        my ha->sas ha.11dd dev gone = my dev gone;
       my ha->sas ha. 11dd max execute num = 11dd max execute num; (1)
       my ha->sas ha. 11dd queue size = ha can queue;
        my ha->sas ha.11dd execute task = my execute task;
        my ha->sas ha.lldd abort task
                                          = my abort task;
        my_ha->sas_ha.11dd_abort_task_set = my_abort_task_set;
       my_ha->sas_ha.11dd_clear_aca
                                          = my clear aca;
       my_ha->sas_ha.lldd_clear_task_set = my_clear_task_set;
       my_ha->sas_ha.11dd_I_T_nexus_reset= NULL; (2)
        my_ha->sas_ha.11dd_lu_reset
                                         = my lu reset;
        my ha->sas ha.11dd query task
                                        = my_query_task;
        my ha->sas ha.11dd clear nexus port = my clear nexus port;
       my ha->sas ha.11dd clear nexus ha = my clear nexus ha;
       my ha->sas ha.11dd control phy = my control phy;
       return sas register ha(&my ha->sas ha);
}
```

(1) This is normally a LLDD parameter, something of the lines of a task collector. What it tells the SAS Layer is whether the SAS layer should run in Direct Mode (default: value 0 or 1) or Task Collector Mode (value greater than 1).

In Direct Mode, the SAS Layer calls Execute Task as soon as it has a command to send to the SDS, _and_ this is a single command, i.e. not linked.

Some hardware (e.g. aic94xx) has the capability to DMA more than one task at a time (interrupt) from host memory. Task Collector Mode is an optional feature for HAs which support this in their hardware. (Again, it is completely optional even if your hardware supports it.)

In Task Collector Mode, the SAS Layer would do _natural_ coalescing of tasks and at the appropriate moment it would call your driver to DMA more than one task in a single HA interrupt. DMBS may want to use this by insmod/modprobe setting the lldd_max_execute_num to something greater than 1.

(2) SAS 1.1 does not define I_T Nexus Reset TMF.

Events

Events are _the only way_ a SAS LLDD notifies the SAS layer of anything. There is no other method or way a LLDD to tell the SAS layer of anything happening internally or in the SAS domain.

Phy events:

PHYE LOSS OF SIGNAL,

PHYE OOB DONE,

PHYE OOB ERROR, (C)

PHYE SPINUP HOLD.

Port events, passed on a _phy_:

PORTE BYTES DMAED, (M)

PORTE BROADCAST RCVD, (E)

PORTE LINK RESET ERR, (C)

PORTE TIMER EVENT, (C)

PORTE HARD RESET.

Host Adapter event:

HAE RESET

A SAS LLDD should be able to generate

- at least one event from group C (choice),
- events marked M (mandatory) are mandatory (only one),
 events marked E (expander) if it wants the SAS layer to handle domain revalidation (only one such).
- Unmarked events are optional.

Meaning:

HAE RESET -- when your HA got internal error and was reset.

PORTE_BYTES_DMAED -- on receiving an IDENTIFY/FIS frame

PORTE BROADCAST RCVD -- on receiving a primitive

PORTE LINK RESET ERR -- timer expired, loss of signal, loss of DWS, etc. (*)

PORTE_TIMER_EVENT -- DWS reset timeout timer expired (*)

PORTE HARD RESET -- Hard Reset primitive received.

PHYE_LOSS_OF_SIGNAL -- the device is gone (*)

PHYE_OOB_DONE -- OOB went fine and oob_mode is valid

PHYE OOB ERROR -- Error while doing OOB, the device probably got disconnected. (*)

PHYE_SPINUP_HOLD -- SATA is present, COMWAKE not sent.

(*) should set/clear the appropriate fields in the phy, or alternatively call the inlined sas_phy_disconnected() which is just a helper, from their tasklet.

The Execute Command SCSI RPC:

int (*11dd_execute_task) (struct sas_task *, int num, unsigned long gfp flags);

Used to queue a task to the SAS LLDD. @task is the tasks to @num should be the number of tasks being be executed. queued at this function call (they are linked listed via task::list), @gfp_mask should be the gfp_mask defining the context of the caller.

This function should implement the Execute Command SCSI RPC, or if you're sending a SCSI Task as linked commands, you should also use this function.

That is, when lldd_execute_task() is called, the command(s) go out on the transport *immediately*. There is *no* queuing of any sort and at any level in a SAS LLDD.

The use of task::list is two-fold, one for linked commands, the other discussed below.

It is possible to queue up more than one task at a time, by initializing the list element of struct sas_task, and passing the number of tasks enlisted in this manner in num.

Returns: -SAS_QUEUE_FULL, -ENOMEM, nothing was queued; 0, the task(s) were queued.

If you want to pass num > 1, then either

- A) you're the only caller of this function and keep track of what you've queued to the LLDD, or
- B) you know what you're doing and have a strategy of retrying.

As opposed to queuing one task at a time (function call), batch queuing of tasks, by having num > 1, greatly simplifies LLDD code, sequencer code, and _hardware design_, and has some performance advantages in certain situations (DBMS).

The LLDD advertises if it can take more than one command at a time at lldd_execute_task(), by setting the lldd_max_execute_num parameter (controlled by "collector" module parameter in aic94xx SAS LLDD).

You should leave this to the default 1, unless you know what you're doing.

This is a function of the LLDD, to which the SAS layer can cater to.

int 11dd queue size

The host adapter's queue size. This is the maximum number of commands the 11dd can have pending to domain devices on behalf of all upper layers submitting through 11dd execute task().

You really want to set this to something (much) larger than 1.

This _really_ has absolutely nothing to do with queuing. There is no queuing in SAS LLDDs.

task_proto -- _one_ of enum sas_proto scatter -- pointer to scatter gather list array num_scatter -- number of elements in scatter total_xfer_len -- total number of bytes expected to be transferred data_dir -- PCI_DMA_... task_done -- callback when the task has finished execution

};

When an external entity, entity other than the LLDD or the SAS Layer, wants to work with a struct domain_device, it _must_ call kobject_get() when getting a handle on the device and kobject put() when it is done with the device.

This does two things:

A) implements proper kfree() for the device;

B) increments/decrements the kref for all players: domain device

all domain_device's ... (if past an expander) port

host adapter
pci device

and up the ladder, etc.

DISCOVERY

The sysfs tree has the following purposes:

- a) It shows you the physical layout of the SAS domain at the current time, i.e. how the domain looks in the physical world right now.
- b) Shows some device parameters at discovery time.

This is a link to the tree(1) program, very useful in viewing the SAS domain:

ftp://mama.indstate.edu/linux/tree/

I expect user space applications to actually create a graphical interface of this.

That is, the sysfs domain tree doesn't show or keep state if you e.g., change the meaning of the READY LED MEANING setting, but it does show you the current connection status of the domain device.

Keeping internal device state changes is responsibility of upper layers (Command set drivers) and user space.

When a device or devices are unplugged from the domain, this is reflected in the sysfs tree immediately, and the device(s) removed from the system.

The structure domain_device describes any device in the SAS domain. It is completely managed by the SAS layer. A task points to a domain device, this is how the SAS LLDD knows where to send the task(s) to. A SAS LLDD only reads the contents of the domain_device structure, but it never creates or destroys one.

第8页

Expander management from User Space

In each expander directory in sysfs, there is a file called "smp_portal". It is a binary sysfs attribute file, which implements an SMP portal (Note: this is *NOT* an SMP port), to which user space applications can send SMP requests and receive SMP responses.

Functionality is deceptively simple:

- 1. Build the SMP frame you want to send. The format and layout is described in the SAS spec. Leave the CRC field equal 0. open(2)
- 2. Open the expander's SMP portal sysfs file in RW mode. write(2)
- 3. Write the frame you built in 1. read(2)
- 4. Read the amount of data you expect to receive for the frame you built. If you receive different amount of data you expected to receive, then there was some kind of error.

All this process is shown in detail in the function do_smp_func() and its callers, in the file "expander_conf.c".

The kernel functionality is implemented in the file "sas_expander.c".

The program "expander_conf.c" implements this. It takes one argument, the sysfs file name of the SMP portal to the expander, and gives expander information, including routing tables.

The SMP portal gives you complete control of the expander, so please be careful.