regulator. txt

Regulator Driver Interface

The regulator driver interface is relatively simple and designed to allow regulator drivers to register their services with the core framework.

${\tt Registration}$

Drivers can register a regulator by calling :-

This will register the regulators capabilities and operations to the regulator core.

Regulators can be unregistered by calling :-

void regulator_unregister(struct regulator_dev *rdev);

Regulator Events

===========

Regulators can send events (e.g. over temp, under voltage, etc) to consumer drivers by calling:-