```
usb.txt
* USB (Universal Serial Bus Controller)

Properties:
    compatible : "fsl,cpm1-usb", "fsl,cpm2-usb", "fsl,qe-usb"

Example:
    usb@11bc0 {
        #address-cells = <1>;
        #size-cells = <0>;
        compatible = "fsl,cpm2-usb";
        reg = <11b60 18 8b00 100>;
        interrupts = <b 8>;
        interrupt-parent = <&PIC>;
        fsl,cpm-command = <2e600000>;
};
```