A. Introduction

This is a framebuffer driver for various Intel 8xx/9xx compatible graphics devices. These would include:

Intel 830M

Intel 845G

Intel 852GM

Intel 855GM

Intel 865G

Intel 915G

Intel 915GM

Intel 945G

Intel 945GM

Intel 945GME

Intel 965G

Intel 965GM

B. List of available options

a. "video=intelfb"

enables the intelfb driver

Recommendation: required

b. "mode=\large xres \rangle x \rangle yres \rangle [-\large bpp \rangle] [@\large refresh \rangle]"

select mode

Recommendation: user preference

(default = 1024x768-32@70)

c. "vram=<value>"

select amount of system RAM in MB to allocate for the video memory if not enough RAM was already allocated by the BIOS.

Recommendation: 1 - 4 MB.

(default = 4 MB)

d. "voffset=<value>"

select at what offset in MB of the logical memory to allocate the framebuffer memory. The intent is to avoid the memory blocks used by standard graphics applications (XFree86). Depending on your usage, adjust the value up or down, (0 for maximum usage, 63/127 MB for the least amount). Note, an arbitrary setting may conflict with XFree86.

Recommendation: do not set

(default = 48 MB)

e. "accel"

enable text acceleration. This can be enabled/reenabled anytime by using 'fbset -accel true/false'.

Recommendation: enable

intelfb. txt

(default = set)

f. "hwcursor" enable cursor acceleration.

Recommendation: enable (default = set)

g. "mtrr"

enable MTRR. This allows data transfers to the framebuffer memory to occur in bursts which can significantly increase performance. Not very helpful with the intel chips because of 'shared memory'.

Recommendation: set
(default = set)

h. "fixed" disable mode switching.

Recommendation: do not set (default = not set)

The binary parameters can be unset with a "no" prefix, example "noaccel". The default parameter (not named) is the mode.

C. Kernel booting

Separate each option/option-pair by commas (,) and the option from its value with an equals sign (=) as in the following:

video=intelfb:option1, option2=value2

Sample Usage

In /etc/lilo.conf, add the line:

append="video=intelfb:mode=800x600-32@75, accel, hwcursor, vram=8"

This will initialize the framebuffer to 800×600 at 32bpp and 75Hz. The framebuffer will use 8 MB of System RAM. hw acceleration of text and cursor will be enabled.

Remarks

If setting this parameter doesn't work (you stay in a 80x25 text-mode), you might need to set the "vga=mode" parameter too - see vesafb.txt in this directory.

D. Module options

The module parameters are essentially similar to the kernel parameters. The main difference is that you need to include a Boolean value (1 for TRUE, and 0 for FALSE) for those options which don't need a value.

第 2 页

intelfb. txt

Example, to enable MTRR, include "mtrr=1".

Sample Usage

Using the same setup as described above, load the module like this:

modprobe intelfb mode=800x600-32@75 vram=8 accel=1 hwcursor=1

Or just add the following to /etc/modprobe.conf

options intelfb mode= $800 \times 600 - 32@75$ vram=8 accel=1 hwcursor=1 and just do a

modprobe intelfb

E. Acknowledgment:

- Geert Uytterhoeven his excellent howto and the virtual framebuffer driver code made this possible.
- 2. Jeff Hartmann for his agggart code.
- 3. David Dawes for his original kernel 2.4 code.
- 4. The X developers. Insights were provided just by reading the XFree86 source code.
- 5. Antonino A. Daplas for his inspiring i810fb driver.
- 6. Andrew Morton for his kernel patches maintenance.

Sylvain