## fw-decoder-api.txt

Decoder firmware API description

Note: this API is part of the decoder firmware, so it's cx23415 only.

CX2341X DEC PING FW Name

Enum 0/0x00Description

> This API call does nothing. It may be used to check if the firmware is responding.

CX2341X DEC START PLAYBACK Name

Enum 1/0x01Description

Begin or resume playback.

Param[0]

O based frame number in GOP to begin playback from.

Param[1]

Specifies the number of muted audio frames to play before normal audio resumes. (This is not implemented in the firmware, leave at 0)

CX2341X DEC STOP PLAYBACK Name

Enum 2/0x02Description

> Ends playback and clears all decoder buffers. If PTS is not zero, playback stops at specified PTS.

Param[0]

Display O=last frame, 1=black

Note: this takes effect immediately, so if you want to wait for a PTS, then use '0', otherwise the screen goes to black at once. You can call this later (even if there is no playback) with a 1 value

to set the screen to black.

Param[1]

PTS low

Param[2]

PTS high

CX2341X DEC SET PLAYBACK SPEED Name

Enum 3/0x03Description

Playback stream at speed other than normal. There are two modes of operation:

Smooth: host transfers entire stream and firmware drops unused

frames.

Coarse: host drops frames based on indexing as required to achieve

desired speed.

Param[0]

Bitmap:

```
fw-decoder-api.txt
```

0:7 0 normal

1 fast only "1.5 times" n nX fast, 1/nX slow

30 Framedrop:

'0' during 1.5 times play, every other B frame is dropped
'1' during 1.5 times play, stream is unchanged (bitrate
must not exceed 8mbps)

31 Speed:

'0' slow '1' fast

Note: n is limited to 2. Anything higher does not result in faster playback. Instead the host should start dropping frames.

Param[1]

Direction: 0=forward, 1=reverse

Note: to make reverse playback work you have to write full GOPs in reverse order.

Param[2]

Picture mask:

1=I frames

3=I, P frames

7=I, P, B frames

Param[3]

B frames per GOP (for reverse play only)

Note: for reverse playback the Picture Mask should be set to I or I, P. Adding B frames to the mask will result in corrupt video. This field has to be set to the correct value in order to keep the timing correct.

Param[4]

Mute audio: 0=disable, 1=enable

Param[5]

Display 0=frame, 1=field

Param[6]

Specifies the number of muted audio frames to play before normal audio resumes. (Not implemented in the firmware, leave at 0)

\_\_\_\_\_

Name CX2341X DEC STEP VIDEO

Enum 5/0x05

Description

Each call to this API steps the playback to the next unit defined below in the current playback direction.

Param[0]

0=frame, 1=top field, 2=bottom field

\_\_\_\_\_

Name CX2341X\_DEC\_SET\_DMA\_BLOCK\_SIZE

Enum 8/0x08 Description

Set DMA transfer block size. Counterpart to API 0xC9

Param[0]

DMA transfer block size in bytes. A different size may be specified when issuing the DMA transfer command.

-----

```
fw-decoder-api.txt
        CX2341X DEC GET XFER INFO
Name
Enum
        9/0x09
Description
        This API call may be used to detect an end of stream condition.
Result[0]
        Stream type
Result[1]
        Address offset
Result[2]
        Maximum bytes to transfer
Result[3]
        Buffer fullness
        CX2341X DEC GET DMA STATUS
Name
Enum
        10/0x0A
Description
        Status of the last DMA transfer
Result[0]
        Bit 1 set means transfer complete
        Bit 2 set means DMA error
        Bit 3 set means linked list error
Result[1]
        DMA type: 0=MPEG, 1=OSD, 2=YUV
        CX2341X DEC SCHED DMA FROM HOST
Name
Enum
        11/0x0B
Description
        Setup DMA from host operation. Counterpart to API 0xCC
Param[0]
        Memory address of link list
Param[1]
        Total # of bytes to transfer
Param[2]
        DMA type (0=MPEG, 1=OSD, 2=YUV)
Name
        CX2341X DEC PAUSE PLAYBACK
Enum
        13/0 \times 0D
Description
        Freeze playback immediately. In this mode, when internal buffers are
        full, no more data will be accepted and data request IRQs will be
        masked.
Param[0]
        Display: 0=last frame, 1=black
```

Name CX2341X\_DEC\_HALT\_FW

Enum 14/0x0E Description

The firmware is halted and no further API calls are serviced until 第 3 页

## fw-decoder-api.txt

the firmware is uploaded again.

```
Name
        CX2341X DEC SET STANDARD
Enum
        16/0x10
Description
        Selects display standard
Param[0]
        0=NTSC, 1=PAL
        CX2341X DEC GET VERSION
Name
Enum
        17/0x11
Description
        Returns decoder firmware version information
Result[0]
        Version bitmask:
            Bits 0:15 build
            Bits 16:23 minor
            Bits 24:31 major
Name
        CX2341X DEC SET STREAM INPUT
Enum
        20/0x14
Description
        Select decoder stream input port
Param[0]
        0=memory (default), 1=streaming
Name
        CX2341X DEC GET TIMING INFO
Enum
        21/0x15
Description
        Returns timing information from start of playback
Result[0]
        Frame count by decode order
Result[1]
        Video PTS bits 0:31 by display order
Result[2]
        Video PTS bit 32 by display order
Result[3]
        SCR bits 0:31 by display order
Result[4]
        SCR bit 32 by display order
Name
        CX2341X_DEC_SET_AUDIO_MODE
        22/0x16
Enum
Description
        Select audio mode
Param[0]
```

```
fw-decoder-api.txt
```

Dual mono mode action

0=Stereo, 1=Left, 2=Right, 3=Mono, 4=Swap, -1=Unchanged

Param[1]

Stereo mode action:

0=Stereo, 1=Left, 2=Right, 3=Mono, 4=Swap, -1=Unchanged

CX2341X DEC SET EVENT NOTIFICATION Name

Enum 23/0x17

Description

Setup firmware to notify the host about a particular event.

Counterpart to API 0xD5

Param[0]

Event: 0=Audio mode change between mono, (joint) stereo and dual

channel.

Event: 3=Decoder started

Event: 4=Unknown: goes off 10-15 times per second while decoding.

Event: 5=Some sync event: goes off once per frame.

Param[1]

Notification O=disabled, 1=enabled

Param [2]

Interrupt bit

Param[3]

Mailbox slot, -1 if no mailbox required.

CX2341X DEC SET DISPLAY BUFFERS Name

Enum 24/0x18

Description

Number of display buffers. To decode all frames in reverse playback you

must use nine buffers.

Param[0]

0=six buffers, 1=nine buffers

Name CX2341X DEC EXTRACT VBI

Enum 25/0x19

Description

Extracts VBI data

Param[0]

O=extract from extension & user data, 1=extract from private packets

Result[0]

VBI table location

Result[1]

VBI table size

CX2341X DEC SET DECODER SOURCE Name

Enum 26/0x1A

Description

Selects decoder source. Ensure that the parameters passed to this

API match the encoder settings.

第 5 页

## fw-decoder-api.txt

Param[0]

Mode: 0=MPEG from host, 1=YUV from encoder, 2=YUV from host

Param[1]

YUV picture width

Param[2]

YUV picture height

Param[3]

Bitmap: see Param[0] of API 0xBD

Name CX2341X\_DEC\_SET\_PREBUFFERING

Enum 30/0x1E

Description

Decoder prebuffering, when enabled up to 128KB are buffered for

streams <8mpbs or 640KB for streams >8mbps

Param[0]

0=off, 1=on